

Contents

1. Safety	3
Safety Instructions	3
Approvals	3
General Warning	3
Avoid unintended Start	4
Before Commencing Repair Work	5
2. Introduction	7
Type Code	7
3. Programming	9
How to Programme	9
Programming with MCT-10	9
Programming with LCP 11 or LCP 12	9
Status Menu	11
Quick Menu	11
Main Menu	12
4. Parameter Descriptions	13
Parameter group 0: Operation/Display	13
Parameter Group 1: Load/Motor	18
Parameter Group 2: Brakes	27
Parameter Group 3: Reference/Ramps	30
Parameter Group 4: Limits/Warnings	36
Parameter Group 5: Digital In/Out	39
Parameter Group 6: Analogue In/Out	44
Parameter Group 7: Controllers	50
Parameter Group 8: Communication	52
Parameter Group 13: Smart Logic	57
Parameter Group 14: Special Functions	65
Parameter Group 15: Drive Information	68
Parameter Group 16: Data Readouts	71
5. Parameter Lists	77
6. Troubleshooting	81
Index	82

1. Safety

1

1.1.1. High Voltage Warning



The voltage of the frequency converter is dangerous whenever it is connected to mains. Incorrect installation of the motor or frequency converter may cause damage to the equipment, serious injury or death. Consequently, it is essential to comply with the instructions in this manual as well as local and national rules and safety regulations.

1.1.2. Safety Instructions

- Make sure the frequency converter is properly connected to earth.
- Do not remove mains connections, motor connections or other power connections while the frequency converter is connected to power.
- Protect users against supply voltage.
- Protect the motor against overloading according to national and local regulations.
- The earth leakage current exceeds 3.5 mA.
- The [OFF] key is not a safety switch. It does not disconnect the frequency converter from mains.

1.1.3. Approvals



1.1.4. General Warning



Warning:

Touching the electrical parts may be fatal - even after the equipment has been disconnected from mains.


Also make sure that other voltage inputs have been disconnected, (linkage of DC intermediate circuit).

Be aware that there may be high voltage on the DC link even when the LEDs are turned off.

Before touching any potentially live parts of the VLT Micro Drive, wait at least 4 minutes for all sizes.


Shorter time is allowed only if indicated on the nameplate for the specific unit.

1




Leakage Current
The earth leakage current from the VLT Micro Drive FC 51 exceeds 3.5 mA. According to IEC 61800-5-1 a reinforced Protective Earth connection must be ensured by means of a min. 10mm² Cu or an additional PE wire - with the same cable cross section as the Mains wiring - must be terminated separately.

Residual Current Device
This product can cause a D.C. current in the protective conductor. Where a residual current device (RCD) is used for extra protection, only an RCD of Type B (time delayed) shall be used on the supply side of this product. See also Danfoss Application Note on RCD, MN.90.GX.YY.
Protective earthing of the VLT Micro Drive and the use of RCDs must always follow national and local regulations.




Motor overload protection is possible by setting Parameter 1-90 Motor thermal protection to the value ETR trip. For the North American market: ETR functions provide class 20 motor overload protection, in accordance with NEC.



Installation in high altitudes:
By altitudes above 2km, please contact Danfoss Drives regarding PELV.

1.1.5. IT Mains



IT Mains
Installation on isolated mains source, i.e. IT mains.
Max. supply voltage allowed when connected to mains: 440 V.


As an option, Danfoss offers line filters for improved harmonics performance.

1.1.6. Avoid unintended Start

While the frequency converter is connected to mains, the motor can be started/stopped using digital commands, bus commands, references or via the Local Control Panel.

- Disconnect the frequency converter from mains whenever personal safety considerations make it necessary to avoid unintended start of any motors.
- To avoid unintended start, always activate the [OFF] key before changing parameters.

1.1.7. Disposal Instruction



Equipment containing electrical components must not be disposed of together with domestic waste.
It must be separately collected with electrical and electronic waste according to local and currently valid legislation.

1.1.8. Before Commencing Repair Work

1. Disconnect FC 51 from mains (and external DC supply, if present.)
2. Wait for 4 minutes for discharge of the DC-link.
3. Disconnect DC bus terminals and brake terminals (if present)
4. Remove motor cable

2. Introduction

2


2.1.1. FC Identification

Below is an example of an identification sticker. This sticker is situated on the frequency converter and shows the type and options fitted to the unit. See following tables for details, how to read the Type code string.



Illustration 2.1: This example shows the identification sticker.

2.1.2. Type Code



Description	Pos	Possible choice
Product group	1-3	Adjustable Frequency Converters
Series and product type	4-6	Micro Drive
Power size	7-10	0.18 - 7.5 kW
Mains voltage	11-12	S2: Single phase 200 - 240 V AC T 2: Three phase 200 - 240 V AC T 4: Three phase 380 - 480 V AC
Enclosure	13-15	IP20/Chassis
RFI filter	16-17	HX: No RFI filter H1: RFI filter class A1/B H3: RFI filter A1/B (reduced cable length)
Brake	18	B: Brake chopper included X: No brake chopper included
Display	19	X: No Local Control Panel N: Numerical Local Control Panel (LCP) P: Numerical Local Control Panel (LCP) with potentiometer
Coating PCB	20	C: Coated PCB X: No coated PCB
Mains option	21	X: No mains option
Adaptation A	22	No adaptation
Adaptation B	23	No adaptation
Software release	24-27	Latest release - std. software

Table 2.1: Type code description

2.1.3. Symbols

Symbols used in this Programming Guide.



NB!

Indicates something to be noted by the reader.



Indicates a general warning.



Indicates a high-voltage warning.

*

Indicates default setting

2.1.4. Abbreviations and Standards

Terms:	Abbreviations:	SI-units:	I-P units:
Acceleration		m/s ²	ft/s ²
American wire gauge	AWG		
Automatic Motor Tuning	AMT		
Current		A	Amp
Current limit	I _{LIM}		
Energy		J = N·m	ft-lb, Btu
Fahrenheit	°F		
Frequency Converter	FC		
Frequency		Hz	Hz
Kilohertz	kHz		
Local Control Panel	LCP		
Milliampere	mA		
Millisecond	ms		
Minute	min		
Motion Control Tool	MCT		
Motor Type Dependent	M-TYPE		
Newton Metres	Nm		
Nominal motor current	I _{M,N}		
Nominal motor frequency	f _{M,N}		
Nominal motor power	P _{M,N}		
Nominal motor voltage	U _{M,N}		
Parameter	par.		
Protective Extra Low Voltage	PELV		
Power		W	Btu/hr, hp
Pressure		Pa = N/m ²	psi, psf, ft of water
Rated Inverter Output Current	I _{INV}		
Revolutions Per Minute	RPM		
Size Related	SR		
Temperature		°C	°F
Time		s	s,hr
Torque limit	T _{LIM}		
Voltage		V	V

Table 2.2: Abbreviation and Standards table .

3. Programming

3.1. How to Programme

3.1.1. Programming with MCT-10

The frequency converter can be programmed from a PC via RS485 com-port by installing the MCT-10 Set-up Software.

This software can either be ordered using code number 130B1000 or downloaded from the Danfoss Web site: www.danfoss.com, Business Area: Motion Controls.

Please refer to manual MG.10.RX.YY.

3.1.2. Programming with LCP 11 or LCP 12

The LCP is divided into four functional groups:

1. Numeric display.
2. Menu key.
3. Navigation keys.
4. Operation keys and indicator lights (LEDs).




Illustration 3.1: LCP 12 with potentiometer




Illustration 3.2: LCP 11 without potentiometer

The display:

A number of information can be read from the display.

Set-up number shows the active set-up and the edit set-up. If the same set-up acts as both active and edit set-up, only that set-up number is shown (factory setting).

When active and edit set-up differ, both numbers are shown in the display (Setup 12). The number flashing, indicates the edit set-up.




Illustration 3.3: Indicating Set-up

The small digits to the left are the selected **parameter number** .




Illustration 3.4: Indicating selected par. no.

The large digits in the middle of the display show the **value** of the selected parameter.




Illustration 3.5: Indicating value of selected par.

The right side of the display shows the **unit** of the selected parameter. This can be either Hz, A, V, kW, HP, %, s or RPM.




Illustration 3.6: Indicating unit of selected par.

Motor direction is shown to the bottom left of the display - indicated by a small arrow pointing either clockwise or counterclockwise.




Illustration 3.7: Indicating motor direction

Use the [MENU] key to select one of the following menus:

Status Menu:

The Status Menu is either in *Readout Mode* or *Hand on Mode*. In *Readout Mode* the value of the currently selected readout parameter is shown in the display.

In *Hand on Mode* the local LCP reference is displayed.

Quick Menu:

Displays Quick Menu parameters and their settings. Parameters in the Quick Menu can be accessed and edited from here. Most applications can be run by setting the parameters in the Quick Menu.

Main Menu:

Displays Main Menu parameters and their settings. All parameters can be accessed and edited here. A parameter overview is found later in this chapter.

Indicator lights:

- Green LED: Power is on the frequency converter.
- Yellow LED: Indicates a warning.
- Flashing red LED: Indicates an alarm.

Navigation Keys:

[Back]: For moving to the previous step or layer in the navigation structure.

Arrows [▲] [▼]: For manoeuvring between parameter groups, parameters and within parameters.

[OK]: For selecting a parameter and for accepting changes to parameter settings.

Operation Keys:

A yellow light above the operation keys indicates the active key.

[Hand on]: Starts the motor and enables control of the frequency converter via the LCP.

[Off/Reset]: The motor stops except in alarm mode. In that case the motor will be reset.

[Auto on]: The frequency converter is controlled either via control terminals or serial communication.

[Potentiometer] (LCP12): The potentiometer works in two ways depending on the mode in which the frequency converter is running.

In *Auto Mode* the potentiometer acts as an extra programmable analog input.

In *Hand on Mode* the potentiometer controls local reference.

3.2. Status Menu

After power up the Status Menu is active. Use the [MENU] key to toggle between Status, Quick Menu and Main Menu.

Arrows [▲] and [▼] toggles between the choices in each menu.

The display indicates the status mode with a small arrow above "Status".




Illustration 3.8: Indicating Status mode

3.3. Quick Menu

The Quick Menu gives easy access to the most frequently used parameters.

1. To enter the Quick Menu, press [MENU] key until indicator in display is placed above *Quick Menu*, then press [OK].
2. Use [▲] [▼] to browse through the parameters in the Quick Menu.
3. Press [OK] to select a parameter.
4. Use [▲] [▼] to change the value of a parameter setting.
5. Press [OK] to accept the change.
6. To exit, press either [Back] twice to enter *Status*, or press [Menu] once to enter *Main Menu*.




Illustration 3.9: Indicating Quick Menu mode

3.4. Main Menu

The Main Menu gives access to all parameters.

1. To enter the Main Menu, press [MENU] key until indicator in display is placed above *Main Menu*.
2. Use [▲] [▼] to browse through the parameter groups.
3. Press [OK] to select a parameter group.
4. Use [▲] [▼] to browse through the parameters in the specific group.
5. Press [OK] to select the parameter.
6. Use [▲] [▼] to set/change the parameter value.
7. Press [OK] to accept the value.
8. To exit, press either [Back] twice to enter *Quick Menu*, or press [Menu] once to enter *Status*.




Illustration 3.10: Indicating Main Menu mode

4. Parameter Descriptions

4.1. Parameter group 0: Operation/Display

0-03 Regional Settings

Option:
Function:

In order to meet the needs for different default settings in different parts of the world, par. 0-03, *Regional Settings*, is implemented in the frequency converter. The selected setting influences the default setting of the motor nominal frequency.

[0] * International

Sets default of par. 1-23, *Motor Frequency*, to 50 Hz.

[1] US

Sets default of par. 1-23, *Motor Frequency*, to 60 Hz.


NB!

This parameter cannot be adjusted while motor runs.

0-04 Operating State at Power-up (Hand Mode)

Option:
Function:

This parameter controls whether or not the frequency converter should start running the motor when powering up after a power down in Hand mode.


NB!

If LCP with potmeter is mounted, reference is set according to actual potmeter value.

[0] Resume

Frequency converter starts in same Hand or Off State as when powered off.

Local reference is stored and used after power-up.

[1] * Forced Stop, Ref=Old

Frequency converter powers up in Off State meaning that motor is stopped after power up.

Local reference is stored and used after power-up.

[2] Forced Stop, Ref=0

Frequency converter powers up in Off State meaning that motor is stopped after power up.

Local reference is set to 0. Thus motor will not start running before local reference has been increased.

4.1.1. 0-1* Set-up Handling

User defined parameters and miscellaneous external inputs (eg. bus, LCP, analog/digital inputs, feedback, etc.) controls the functionality of the frequency converter.

A complete set of all parameters controlling the frequency converter is called a set-up. The Micro Drive FC 51 contains 2 set-ups, *Set-up1* and *Set-up 2*.

Furthermore, a fixed set of factory settings can be copied into one or more set-ups.

Some of the advantages of having more than one set-up in the frequency converter are

- Run motor in one set-up (Active Set-up) while updating parameters in another set-up (Edit Set-up)
- Connect various motors (one at a time) to frequency converter. Motor data for various motors can be placed in different set-ups.
- Rapidly change settings of frequency converter and/or motor while motor is running (eg. ramp time or preset references) via bus or digital inputs.

The *Active Set-up* can be set as *Multi Set-up* where the active set-up is selected via input on a digital input terminal and/or via the bus control word.



NB!

FactorySet-up cannot be used as *Active Set-up*.

0-10 Active Set-up

Option:

Function:

Active Set-up controls the motor.
Shifts between set-ups can only happen when

- the motor is coasted

OR

- the set-ups between which the shift happens are linked to each other (see par. 0-12, *Linked Set-ups*).

If changing between set-ups that are not linked, the change will not happen before motor is coasted.



NB!

The motor is only considered stopped when it is coasted.

[1] *	Set-up 1	<i>Set-up 1</i> is active.
[2]	Set-up 2	<i>Set-up 2</i> is active.
[9]	Multi Set-up	Select the active set-up via digital input and/or bus, see par. 5-1* choice [23].

0-11 Edit Set-up

Option:

Function:

The *Edit Set-up* is for updating parameters in the frequency converter from either LCP or bus. It can be identical or different from the *Active Set-up*.

All set-ups can be edited during operation, independently of the active set-up.

[1] *	Set-up 1	Update parameters in <i>Set-up 1</i> .
[2]	Set-up 2	Update parameters in <i>Set-up 2</i> .

[9]	Active Set-up	Update parameters in set-up selected as <i>Active Set-up</i> (see par. 0-10).
-----	---------------	---

0-12 Link Set-ups

Option:	Function:
	The link ensures synchronizing of the "not changeable during operation" parameter values enabling shift from one set-up to another during operation.
	If the set-ups are not linked, a change between them is not possible while the motor is running. Thus the set-up change does not occur until the motor is coasted.

[0]	Not linked	Leaves parameters unchanged in both set-ups and cannot be changed while motor runs.
-----	------------	---

[1] *	Linked	Copy parameters "not changeable during operation" parameter values into presently selected <i>Edit Set-up</i> .
--------	--------	---



NB!

This parameter cannot be changed while motor runs.

4.1.2. 0-4* LCP Keypad

The frequency converter can operate in the following three modes: *Hand*, *Off* and *Auto*.

Hand: The frequency converter is locally operated and does not allow any remote control. By activating Hand a start signal is given.

OFF: The frequency converter stops with a normal stop ramp. When Off is chosen the frequency converter can only be started by pressing either Hand or Auto on the LCP.

Auto: In Auto-mode the frequency converter can be remote controlled (bus/digital).

0-40 [Hand on] Key on LCP

Option:	Function:	
[0]	Disabled	Hand-on key has no function.
[1] *	Enabled	Hand-on key is functional.

0-41 [Off/Reset] Key on LCP

Option:	Function:	
[0]	Disable Off/Reset	Off/reset key has no function.
[1] *	Enable Off/Reset	Stop signal and reset of any faults.
[2]	Enable Reset Only	Reset only. Stop (Off) function is disabled.

0-42 [Auto on] Key on LCP

Option:	Function:	
[0]	Disabled	Auto-on key has no function.
[1] *	Enabled	Auto-on key is functional.

4.1.3. 0-5* Copy/Save

0-50 LCP Copy

Option:
Function:

The detachable LCP of the frequency converter can be used for storing setups, and thus for transferring data when moving parameter settings from one frequency converter to another.


NB!

LCP Copy can only be activated from the LCP and ONLY when the motor is coasted.

[1]	All to LCP	Copy all setups from the frequency converter into the LCP.
[2]	All from LCP	Copy all setups from LCP to frequency converter.
[3]	Size indep. from LCP	Copy non motor size dependent data from LCP to frequency converter

0-51 Set-up Copy

Option:
Function:

Use this function to copy a set-up content into the *Edit Set-up*. In order to be able to make a set-up copy ensure that

- the motor is coasted
- par. 0-10, *Active Set-up*, is set to either *Set-up 1* [1] or *Set-up 2* [2]


NB!

The keyboard/parameter database are blocked while Set-up Copy is running.

[0] *	No Copy	Copy function is inactive
[1]	Copy from Set-up 1	Copy from <i>Set-up 1</i> to edit set-up chosen in par. 0-11, <i>Edit Set-up</i> .
[2]	Copy from Set-up 2	Copy from <i>Set-up 2</i> to edit set-up chosen in par. 0-11, <i>Edit Set-up</i> .
[9]	Copy from Factory Set-up	Copy from Factory Settings to edit set-up chosen in par. 0-11, <i>Edit set-up</i> .

4.1.4. 0-6* Password

0-60 (Main) Menu Password

Range:
Function:

Use password for protection against unintended change of sensitive parameters, eg. motor parameters.

Password protected parameters can always be read, but cannot be edited without entering the password.

0 *	[0 - 999]	Enter the password for access to Main Menu via the [Main Menu] key. Select the number that should allow for changing other parameter values. 0 means there is no password.
-----	-----------	--

**NB!**

A password only has affect on the LCP - not on the bus communication.

4.2. Parameter Group 1: Load/Motor

1-00 Configuration Mode

Option:
Function:

Use this parameter for selecting the application control principle to be used when a Remote Reference is active.


NB!

Changing this parameter will reset parameters 3-00, 3-02 and 3-03 to their default values.


NB!

This parameter cannot be adjusted while motor runs.

[0] * Speed Open Loop

For normal speed control (References).

[3] Process Closed Loop

Enables process closed loop control. See par. group 7-3* for further information on PI-controller.

When running in process closed loop, par. 4-10 *Motor Speed Direction* must be set to *Clockwise* [0]

1-01 Motor Control Principle

Option:
Function:

[0] U/f

Is used for parallel connected motors and/or special motor applications. The U/f settings are set in parameters 1-55 and 1-56.


NB!

When running U/f control slip- and load compensations are not included.

[1] * VVC+

Normal running mode, including slip- and load compensations.

1-03 Torque Characteristics

Option:
Function:

With more torque characteristics it is possible to run low energy consuming, as well as high torque applications.

[0] * Constant Torque

Motor shaft output provides constant torque under variable speed control.

[2] Automatic Energy Optim.

This function automatically optimizes energy consumption in centrifugal pump and fan applications. See par. 14-41 *AEO Minimum Magnetisation*.

1-05 Hand Mode Configuration

Option:	Function:
	This parameter is only relevant when parameter 1-00 <i>Configuration Mode</i> is set to <i>Process Closed Loop</i> [3]. The parameter is used for determining the reference or setpoint handling when changing from Auto Mode to Hand Mode on the LCP.
[0] Speed Open Loop	In Hand Mode the drive always runs in Open Loop configuration regardless of setting in par. 1-00 <i>Configuration Mode</i> . Local potentiometer (if present) or Arrow up/down determines output frequency limited by Motor Speed High/Low Limit (parameters 4-14 and 4-12).
[2] * As configuration in par. 1-00	If par. 1-00 <i>Configuration Mode</i> is set to <i>Open Loop</i> [1] function is as described above. If par. 1-00 is set to <i>Process Closed Loop</i> [3] changing from Auto mode to Hand mode results in a setpoint change via local potentiometer or Arrow up/down. The change is limited by Reference Max/Min (parameters 3-02 and 3-03).

4.2.1. 1-2* Motor Data

Enter the correct motor nameplate data (power, voltage, frequency, current and speed).
Run AMT, see par. 1-29.
Factory settings for advanced motor data, par. 1-3*, are automatically calculated.

NB!
Parameters in parameter group 1.2* cannot be adjusted while motor runs.

1-20 Motor Power [kW]/[HP] (P_{m.n})

Range:	Function:
	Enter motor power from nameplate data.
[0.09 kW/0.12 HP - 11 kW/15 HP]	Two sizes down, one size up from nominal VLT rating.
	<div style="border: 1px solid black; padding: 5px;"> <p>NB! Changing this parameter affects par. 1-22 to 1-25, 1-30, 1-33 and 1-35.</p> </div>

1-22 Motor Voltage (U_{m.n})

Range:	Function:
230/400 [50 - 999 V] V	Enter motor voltage from nameplate data.

1-23 Motor Frequency (f_{m.n})

Range:	Function:
50 Hz* [20-400 Hz]	Enter motor frequency from nameplate data.

1-24 Motor Current ($I_{m,n}$)

Range:	Function:
M-type [0.01 - 26.00 A] depend- ent*	Enter motor current from nameplate data.

1-25 Motor Nominal Speed ($n_{m,n}$)

Range:	Function:
M-type [100 - 9999 RPM] Depend- ent*	Enter motor nominal speed from nameplate data.

1-29 Automatic Motor Tuning (AMT)

Option:	Function:
	Use AMT to optimize motor performance.

**NB!**

This parameter cannot be changed while motor runs.

1. Stop VLT – make sure motor is at standstill
2. Choose [2] Enable AMT
3. Apply start signal
 - Via LCP: Press Hand On
 - Or in Remote On mode: Apply start signal on terminal 18

[0] *	Off	AMT function is disabled.
[2]	Enable AMT	AMT function starts running.

**NB!**

To gain optimum tuning of frequency converter, run AMT on a cold motor.


4.2.2. 1-3* Adv. Motor Data

Adjust advanced motor data using one of these methods:

1. Run AMT on cold motor. Frequency converter measures value from motor.
2. Enter X_1 value manually. Obtain value from motor supplier.
3. Use X_1 default setting. Frequency converter establishes setting based on motor nameplate data.

**NB!**

This parameter cannot be changed while motor runs.



1-30 Stator Resistance (R_s)

Range:

Depend- [Ohm]
ing
on mo-
tor
data*

Function:

Set stator resistance value.

1-33 Stator Leakage Reactance (X_1)

Range:

Depend- [Ohm]
ing on
motor
data*

Function:

Set stator leakage reactance of motor.

1-35 Main Reactance (X_2)

Range:

Depend- [Ohm]
ing on
motor
data*

Function:

Set motor main reactance.

4.2.3. 1-5* Load Independent Setting

This parameter group is for setting the load independent motor settings.

1-50 Motor Magnetization at Zero Speed

Range:

100 %* [0 - 300%]

Function:

This parameter enables different thermal load on motor when running at low speed.

Enter a percentage of rated magnetizing current. If setting is too low, motor shaft torque may be reduced.


1-52 Min. Speed Normal Magnetizing [Hz]

Range:

Function:

Use this parameter along with par. 1-50, *Motor Magnetizing at Zero Speed*.

0.0 Hz* [0.0 - 10.0 Hz] Set frequency required for normal magnetizing current. If frequency is set lower than motor slip frequency, par. 1-50, *Motor Magnetizing at Zero Speed* is inactive.



1-55 U/f Characteristic - U

Range: **Function:**
 This parameter is an array parameter [0-5] and is only functional when par. 1-01, *Motor Control Principle* is set to *U/f[0]*.

0.0 V* [0.0 - 999.9 V] Enter voltage at each frequency point to manually form a U/f characteristic matching motor. Frequency points are defined in par. 1-56, *U/f characteristics - F*.

1-56 U/f Characteristic - F

Range: **Function:**
 This parameter is an array parameter [0-5] and is only functional when par. 1-01, *Motor Control Principle* is set to *U/f[0]*.

0.0 Hz* [0.0 - 1000.0 Hz] Enter frequency points to manually form a U/f characteristic matching motor. Voltage at each point is defined in par. 1-55, *U/f Characteristic - U*.
 Make a U/f characteristic based on 6 definable voltages and frequencies, see below figure.
 Simplify U/f characteristics by merging 2 or more points (voltages and frequencies), respectively, are set equal.





Illustration 4.1: Fig. 1 U/f characteristics

NB!
 For par. 1-56 the following applies
 $[0] \leq [1] \leq [2] \leq [3] \leq [4] \leq [5]$

4.2.4. 1-6* Load Dependent setting

Parameters for adjusting the load dependent motor settings.

1-60 Low Speed Load Compensation	
Range:	Function:
100 %* [0-199 %]	Use this parameter to gain optimum U/f characteristic when running at low speed.
	Enter percentage in relation to load when motor runs at low speed.
	Change-over point is automatically calculated based on motor size.



1-61 High Speed Load Compensation	
Range:	Function:
100 %* [0 - 199 %]	Use this parameter to obtain optimum load compensation when running at high speed.
	Enter percentage to compensate in relation to load when motor runs at high speed.
	Change-over point is automatically calculated based on motor size.

1-62 Slip Compensation	
Range:	Function:
100 %* [-400 - 399 %]	Compensation for load dependent motor slip.
	Slip compensation is calculated automatically based on rated motor speed, $n_{M,N}$.
<div style="border: 1px solid black; padding: 5px;"> <p>NB! This function is only active when par. 1-00, <i>Configuration Mode</i>, is set to <i>Speed Open Loop</i> [0], and when par. 1-01, <i>Motor Control Principle</i>, is set to <i>VVC+</i> [1].</p> </div>	

1-63 Slip Compensation Time

Range:	Function:
0.10 s [0.05 - 5.00 s]	Enter slip compensation reaction speed. A high value results in slow reaction whereas a low value results in quick reaction. If low-frequency resonance problems arise, use longer time setting.

4.2.5. 1-7* Start Adjustments

Considering the need for various start functions in different applications, it is possible to select a number of functions in this parameter group.

1-71 Start Delay

Range:	Function:
0.0 s* [0.0 - 10.0 s]	The start delay defines the time to pass from a start command is given until the motor starts accelerating. Setting start delay to 0.0 sec. disables <i>Start Function</i> , [1-72], when start command is given. Enter the time delay required before commencing acceleration. Par. 1-72 <i>Start Function</i> is active during <i>Start delay time</i> .

1-72 Start Function

Option:	Function:
[0] DC Hold/Delay Time	Motor is energized with DC holding current (par. 2-00) during start delay time.
[1] DC Brake/Delay Time	Motor is energized with DC braking current (par. 2-01) during start delay time.
[2] * Coast/Delay Time	Inverter is coasted during start delay time (inverter off).

1-73 Flying Start

Option:	Function:
	Use flying start to catch a spinning motor after eg. mains drop-out.



This function is not suitable for hoisting applications.

[0] * Disabled	Flying start is not required.
[1] Enabled	Frequency converter enabled to catch spinning motor.



NB!
When flying start is enabled par. 1-71, *Start Delay*, and par. 1-72, *Start Function*, have no function.

4.2.6. 1-8* Stop Adjustments

To meet the need for various stop functions in different application these parameters offer some special stop features for the motor.

1-80 Function at Stop

Option:

Function:

The selected function at stop is active in following situations:

- Stop command is given and output speed is ramped down to *Min. Speed for Activating Functions at Stop*.
- Start command is removed (standby), and output speed is ramped down to *Min. Speed for Activating Functions at Stop*.
- DC-brake command is given, and DC-brake time has passed
- While running and calculated output speed is below *Min. Speed for Activating Functions at Stop*.

[0] * Coast

The inverter is coasted.

[1] DC hold

The motor is energized with a DC current. See par. 2-00 *DC Hold Current* for more information.

1-82 Min. Speed For Function at Stop [Hz]

Range:

0.0 Hz* [0.0 - 20.0 Hz]

Function:

Set the speed at which to activate par. 1-80 *Function at Stop*.

4.2.7. 1-9* Motor Temperature

With an estimated motor temperature monitor the frequency converter is able to estimate motor temperature without having a thermistor mounted. It is thus possible to receive a warning or an alarm, if motor temperature exceeds upper operational limit.

1-90 Motor Thermal Protection

Option:

Function:

Using ETR (Electronic Terminal Relay) the motor temperature is calculated based on frequency, speed and time. Danfoss recommends using The ETR function, if a thermistor is not present.



NB!

ETR calculation is based on motor data from group 1-2*.

[0] * No Protection

Disables temperature monitoring.

[1] Thermistor Warning

A thermistor connected to either digital or analog input gives a warning if upper limit of motor temperature range is exceeded, (see par. 1-93, *Thermistor Resource*).

[2]	Thermistor Trip	A thermistor connected to either digital or analog input gives an alarm and makes the frequency converter trip if upper limit of motor temperature range is exceeded, (see par. 1-93, <i>Thermistor Resource</i>).
[3]	ETR Warning	If calculated upper limit of motor temperature range is exceeded, a warning occurs.
[4]	ETR Trip	If calculated upper limit of motor temperature range is exceeded, an alarm occurs and frequency converter trips.

1-93 Thermistor Resource

Option:	Function:
	Select the thermistor input terminal.
[0] * None	No thermistor is connected.
[1] Analog Input 53	Connect thermistor to analog input terminal 53.

NB!
Analog input 53 cannot be selected for other purposes when selected as thermistor resource.

[6] Digital input 29	Connect thermistor to digital input terminal 29. While this input functions as thermistor input, it will not respond to the function chosen in par. 5-13, <i>Digital Input 29</i> . The value of par. 5-13 remains however unchanged in parameter database while function is inactive.
----------------------	---

Input Digital/ Analog	Supply Voltage	Threshold Cut-out Values
Digital	10 V	<800 ohm - >2.9k ohm
Analog	10 V	<800 ohm - >2.9k ohm

4.3. Parameter Group 2: Brakes

4.3.1. 2-** Brakes

4.3.2. 2-0* DC-Brake

The purpose of DC-brake function is to brake a rotating motor by applying DC-current to the motor.

2-00 DC Hold Current

Range:

50%* [0 - 100%]

Function:

This parameter either holds the motor (holding torque) or pre-heats the motor.

The parameter is active if *DC Hold* has been selected in either par. 1-72 *Start Function* or par. 1-80 *Function at Stop*.

Enter a value for holding current as a percentage of the rated motor current set in par. 1-24 *Motor Current*. 100% DC holding current corresponds to $I_{M,N}$.



NB!

Avoid 100% current too long as it may overheat the motor.

2-01 DC Brake Current

Range:

50 %* [0 - 150%]

Function:

Set DC-current needed to brake rotating motor.

Activate DC-brake in one of the four following ways:

1. DC-brake command, see par. 5-1* choice [5]
2. DC Cut-in function, see par. 2-04
3. DC-brake selected as start function, see par. 1-72
4. DC-brake in connection with *Flying Start*, par. 1-73.

2-02 DC-Braking Time

Range:

10.0 s* [0.0 - 60 s]

Function:

DC-braking time defines the period during which *DC-brake current* is applied to the motor.

Set the time DC-braking current, set in par. 2-01, must be applied.



NB!

If DC-brake is activated as start function, DC-brake time is defined by *start delay time*.

2-04 DC-Brake Cut-in Speed

Range: 0.0 Hz* [0.0 - 400.0 Hz]	Function: Set DC-brake cut-in speed to activate DC braking current, set in par. 2-01, when ramping down. When set to 0 the function is off.
---	--

4.3.3. 2-1* Brake Energy Function

Use the parameters in this group for selecting dynamic braking parameters.

2-10 Brake Function

Option:	Function:
	Resistor Brake: The resistor brake limits voltage in the intermediate circuit when the motor acts as generator. Without brake resistor, the frequency converter eventually trips. The resistor brake consumes surplus energy resulting from motor braking. A frequency converter with brake stops a motor faster than without a brake, which is used in many applications. Requires connection of external brake resistor. An alternative to the resistor brake is the AC brake.



NB!

Resistor brake is only functional in frequency converters with integrated dynamic brake. An external resistor must be connected.

AC Brake:

The AC brake consumes surplus energy by creating power loss in the motor.
It is important to keep in mind that an increase in power loss causes motor temperature to rise.

[0] *	Off	No brake function.
[1]	Resistor Brake	Resistor brake is active.
[2]	AC Brake	AC brake is active.

2-11 Brake Resistor (Ohm)

Range: 5 Ω* [5 - 5000 Ω]	Function: Set brake resistor value.
------------------------------------	---

2-16 AC Brake, Max Current

Range: 100.0 % [0.0 - 150.0 %] *	Function: Enter max. permissible current for AC-braking to avoid overheating of motor. 100% equals motor current set in par. 1-24.
---	---

2-17 Over-Voltage Control

Option:	Function:
[0] * Disabled	The OVC is not active/required.
[1] Enabled, not at stop	OVC is running unless a stop signal is active.
[2] Enabled	OVC is running, also when a stop signal is active.



NB!

If Resistor Brake has been chosen in par. 2-10 *Brake Function* the OVC is not active even though enabled in this parameter.

4.3.4. 2-2* Mechanical Brake

For hoisting applications an electro-magnetic brake is required. The brake is controlled by a relay, which releases the brake when activated.

The brake activates if frequency converter trips or a coast command is given. Furthermore, it activates when motor speed is ramped down below the speed set in par. 2-22, *Active Brake Speed*.

2-20 Release Brake Current

Range:	Function:
0.00 A* [0.00 - 100 A]	Select motor current at which mechanical brake releases.



If start delay time has passed, and motor current is below *Release brake current*, frequency converter trips.

2-22 Activating Mechanical Brake

Range:	Function:
0 Hz* [0 - 400 Hz]	<p>If the motor is stopped using ramp, the mechanical brake is activated when motor speed is less than <i>Active Brake Speed</i>. Motor is ramped down to stop in the following situations:</p> <ul style="list-style-type: none"> • A start command is removed (stand by) • A stop command is activated • Quick-stop is activated (Q-stop ramp is used) <p>Select motor speed at which mechanical brake activates when ramping down.</p> <p>Mechanical brake automatically activates if frequency converter trips or reports an alarm.</p>

4.4. Parameter Group 3: Reference/Ramps

4.4.1. 3-** Reference/Ramps

Parameters for reference handling, definition of limitations, and configuration of the frequency converter's reaction to changes

4.4.2. 3-0* Reference Limits

Parameters for setting the reference unit, limits and ranges.

3-00 Reference Range

Option:

Function:

Select the range of reference and feedback signals. Values can be both positive and negative, unless par. 1-00, *Configuration Mode*, is set to *Process Closed Loop* [3]. In that case only positive values are allowed.

[0] * Min - Max

Reference setpoint ranges can have positive values only. Select this if running in Process Closed Loop.

[1] -Max - +Max

Ranges can have both positive and negative values.

3-02 Minimum Reference

Range:

0.00* [-4999 - 4999]

Function:

Enter value for minimum reference.

The sum of all internal and external references are clamped (limited) to the minimum reference value, par. 3-02.

3-03 Maximum Reference

Range:

50.00* [-4999 - 4999]

Function:

Maximum Reference is adjustable in the range Minimum Reference - 4999.

Enter value for Maximum Reference.

The sum of all internal and external references are clamped (limited) to the maximum reference value, par. 3-03.

4.4.3. 3-1* References

Parameters for setting up the reference sources. Select the preset references for the corresponding digital inputs in parameter group 5.1*, *Digital Inputs*.

3-10* Preset Reference

Option:

Function:

Each parameter set-up contains 8 preset references which are selectable via 3 digital inputs or bus.

[18] Bit2	[17] Bit1	[16] Bit0	Preset reference no.
0	0	0	0
0	0	1	1
0	1	0	2
0	1	1	3
1	0	0	4
1	0	1	5
1	1	0	6
1	1	1	7

Table 4.1: Par. 5-1* selection [16], [17] and [18]

[0.00] * -100.00 - 100.00% Enter the different preset references using array programming. Normally, 100% = value set in par. 3-03, *Maximum Reference*. However, there are exceptions if par. 3-00 is set to *Min - Max*, [0].

Example 1:
Par. 3-02 is set to 20 and par. 3-03 is set to 50. In this case 0% = 0 and 100% = 50.

Example 2:
Par. 3-02 is set to -70 and par. 3-03 is set to 50. In this case 0% = 0 and 100% = 70.

3-11 Jog Speed [Hz]

Range:

Function:
Jog speed is a fixed output speed and overrules the selected reference speed, see par. 5-1* selection [14].
If the motor is stopped while in jog mode, the jog signal acts as a start signal.
Removing the jog signal makes the motor run according to the selected configuration.

5.0 Hz [0.0 - 400.0 Hz] Select speed to function as jog speed.

3-12 Catch Up/Slow Down Value

Range:
0% * [0 - 100%]

Function:
The *Catch-up/Slowdown function* is activated by an input command (see par. 5-1*, choice [28]/[29]). If the command is active, the Catch-up/Slowdown value (in %) is added to the reference function as follows:

$$Reference = Reference + reference \times \frac{Catchup\ Slowdown}{100}$$


$$Reference = Reference - reference \times \frac{Catchup\ Slowdown}{100}$$

When the input command is inactivated, the reference returns to its original value ie. Reference = Reference + 0.

3-14 Preset Relative Reference

Range: 0.00% [-100.00 - 100.00%] **Function:** Define fixed value in % to be added to variable value defined in par. 3-18, *Relative Scaling Reference Source*.

The sum of fixed and variable values (labelled Y in illustration below) is multiplied with actual reference (labelled X in illustration). This product is added to actual reference

$$X + X \times \frac{Y}{100}$$


3-15 Reference 1 Source

Option: **Function:** Par. 3-15, 3-16 and 3-17 define up to three different reference signals. The sum of these reference signals defines the actual reference.

[0]	No Function	No reference signal is defined.
[1] *	Analog Input 53	Use signals from analog input 53 as reference, see par. 6-1*.
[2]	Analog Input 60	Use signals from analog input 60 as reference, see par. 6-2*.
[11]	Local Bus Ref.	Use signals from local bus as reference, see par. 8-9*.
[21]	LCP Potentiometer	Use signals from LCP potentiometer as reference, see par. 6-8*.
[8]	Pulse input	Use signals from pulse input as reference, see par. 5-5*.

3-16 Reference 2 Source

Option: **Function:** See Par. 3-15 for description.

[0]	No Function	No reference signal is defined.
[1]	Analog Input 53	Use signals from analog input 53 as reference.
[2] *	Analog Input 60	Use signals from analog input 60 as reference.
[11]	Local Bus Ref.	Use signals from local bus as reference.
[21]	LCP Potentiometer	Use signals from LCP potentiometer as reference.

3-17 Reference 3 Source

Option: **Function:** See Par. 3-15 for description.

[0]	No Function	No reference signal is defined.
[1]	Analog Input 53	Use signals from analog input 53 as reference.

[2]	Analog Input 60	Use signals from analog input 60 as reference.
[11] *	Local Bus Ref.	Use signals from local bus as reference.
[21]	LCP Potentiometer	Use signals from LCP potentiometer as reference.


3-18 Relative Scaling Reference Source

Option:	Function:
[0] *	No Function The function is disabled
[1]	Analog Input 53 Select analog input 53 as relative scaling reference source.
[2]	Analog Input 54 Select analog input 54 as relative scaling reference source.
[8]	Pulse Input 33 Select pulse input 33 as relative scaling reference source.
[11]	Local Bus Ref. Select local bus ref. as relative scaling reference source.
[21]	LCP Potentiometer Select LCP potentiometer as relative scaling reference source.

4.4.4. 3-4* Ramp 1

A linear ramp is characterized by ramping up at a constant speed until the desired motor speed has been reached. Some overshoot may be experienced when reaching speed, which may cause speed jerks for a short while before stabilizing. An S-ramp accelerates more smoothly thus compensating for jerks when the speed is reached.

See the below figure for a comparison of the two ramp types.



Ramp Times:

Ramp up: Acceleration time. From 0 to nominal motor frequency (par. 1-23).
 Ramp down: Deceleration time. From nominal motor frequency (par. 1-23) to 0.

Limitation:

Too short ramp up time can result in Torque limit warning (W12) and/or DC over voltage warning (W7). Ramping is stopped when the frequency converter has reached Torque limit motor mode (par. 4-16).
 Too short ramp down time can result in Torque limit warning (W12) and/or DC over voltage warning (W7). Ramping is stopped when the frequency converter reaches the Torque limit generator mode (par. 4-17) and/or the internal DC over voltage limit.

3-40 Ramp1 Type

Option:	Function:
[0] * Linear	Constant acceleration/deceleration.
[2] S-ramp	Smooth jerk compensated acceleration/deceleration.

3-41 Ramp1 Ramp-up Time

Range:	Function:
3.00 s* [0.05 - 3600 s]	Enter ramp-up time from 0 Hz to rated motor frequency ($f_{M,N}$) set in par. 1-23. Choose a ramp-up time ensuring that torque limit is not exceeded, see par. 4-16.

3-42 Ramp1 Ramp-down Time

Range:	Function:
3.00* [0.05 - 3600 s]	Enter ramp down time from rated motor frequency ($f_{M,N}$) in par. 1-23 to 0 Hz. Choose a ramp down time that does not cause over-voltage in inverter due to regenerative operation of motor. Furthermore, regenerative torque must not exceed limit set in par. 4-17.

4.4.5. 3-5* Ramp2

See par. 3-4* for a description of ramp types.



NB!

Ramp2 - alternative ramp times:
Changing from Ramp1 to Ramp2 is done via the digital input. See par. 5-1*, selection [34].

3-50 Ramp2 Type

Option:	Function:
[0] * Linear	Constant acceleration/deceleration.
[2] S-ramp	Smooth jerk compensated acceleration/deceleration.

3-51 Ramp2 Ramp-up Time

Range:	Function:
3.000 * [0.100 - 3600 s]	Enter ramp-up time from 0 Hz to rated motor frequency ($f_{M,N}$) set in par. 1-23. Choose a ramp-up time ensuring that output current does not exceed current limit set in par. 4-18 during ramping.

3-52 Ramp2 Ramp-down Time

Range:	Function:
3.000 s [0.100 - 3600 s]	Enter ramp down time from rated motor frequency ($f_{M,N}$) in par. 1-23 to 0 Hz.

Choose a ramp down time that does not cause over-voltage in inverter due to regenerative operation of motor. Furthermore, generated current must not exceed current limit set in par. 4-18.

4.4.6. 3-8* Other Ramps

This section contains parameters for Jog and Quick Stop Ramps.

With a Jog Ramp you can both ramp up and down whereas you can only ramp down with the Quick Stop Ramp.

3-80 Jog Ramp Time

Range:

3.000 s* [0.100 - 3600 s]

Function:

A linear ramp applicable when Jog is activated. See par. 5-1*, selection [14].

Ramp up time = Ramp down time.

Jog Ramp time starts upon activation of a jog signal via a selected digital input or serial communication port.

3-81 Quick Stop Ramp Time

Range:

3.000 s* [0.100 - 3600 s]

Function:

A linear ramp applicable when Q-stop is activated. See par. 5-1*, selection [4].

4.5. Parameter Group 4: Limits/Warnings

4.5.1. 4-** Motor Limits

Parameter group for configuring limits and warning.

4.5.2. 4-1* Motor Limits

Use these parameters for defining the speed, torque and current working range for the motor.

4-10 Motor Speed Direction

Option:

Function:

If terminals 96, 97 and 98 are connected to U, V and W respectively, the motor runs clockwise when seen from the front.



NB!

This parameter cannot be adjusted while the motor is running

[0]	Clockwise	The motor shaft rotates in clockwise direction. This setting prevents the motor from running in counterclockwise direction. If par. 1-00 <i>Configuration mode</i> has been set to <i>Process Closed Loop</i> [3] this parameter must always be set to <i>Clockwise</i> .
[1]	Counterclockwise	The motor shaft rotates in counterclockwise direction. This setting prevents the motor from running in clockwise direction.
[2] *	Both	With this setting the motor can run in both directions. However, the output frequency is limited to the range: Motor Speed Low Limit (par. 4-12) to Motor Speed High Limit (par. 4-14).

4-12 Motor Speed Low Limit

Range:

0.0 Hz* [0.0 - 400.0 Hz]

Function:

Set the *Minimum Motor Speed Limit* corresponding to the minimum output frequency of the motor shaft.



NB!

As the minimum output frequency is an absolute value, it cannot be deviated from.

4-14 Motor Speed High Limit

Range:

65.0 [0.0 - 400.0 Hz]
Hz*

Function:

Set the *Maximum Motor Speed* corresponding to the maximum output frequency of the motor shaft.



NB!

As the maximum output frequency is an absolute value, it cannot be deviated from.

4-16 Torque Limit in Motor Mode

Range: 150.0 % [0.0 - 199.9%] *	Function: Set the torque limit for motor operation. The setting is not automatically reset to default when changing settings in par. 1-00 to 1-25 <i>Load & Motor</i> .
--	--

4-17 Torque Limit in Generator Mode

Range: 150.0 % [0.0 - 199.9 %] *	Function: Set the torque limit for generator mode operation. The setting is not automatically reset to default when changing settings in par. 1-00 to 1-25 <i>Load & Motor</i> .
---	---

4

4.5.3. 4-5* Adjustable Warnings

Parameter group containing adjustable warning limits for current, speed, reference and feedback.

Warnings are shown in display, programmed output or serial bus.

4-50 Warning Current Low

Range: 0.00 A [0.00 - 26.00 A]	Function: Use this parameter to set a lower limit for the current range. If current drops below the set limit, a warning occurs.
	Set value for low current limit.

4-51 Warning Current High

Range: 26.00 [0.00 - 26.00 A] A*	Function: Use this parameter to set an upper limit for the current range. If current exceeds the set limit, a warning occurs.
	Set upper current limit.

4-58 Missing Motor Phase Function

Option:	Function: A missing motor phase causes the motor torque to drop. This monitor may be disabled for special purposes (eg. small motors running pure U/f mode), but as there is a risk of overheating the motor, Danfoss strongly recommends that the function is <i>On</i> . A missing motor phases causes the frequency converter to trip and report an alarm.
----------------	--

**NB!**

This parameter cannot be changed while motor runs.

[0]	Off	Function is disabled.
[1]	* On	Function is enabled.

4.5.4. 4-6* Speed Bypass

In some applications mechanical resonance may occur. Avoid resonance points by creating a bypass. The frequency converter ramps through the bypass area thereby passing mechanical resonance points quickly.

4-61 Speed Bypass From [Hz]

Range:

Function:

Array [2]

0.0 Hz* [0.0 - 400.0 Hz]

Enter either the lower or upper limit of the speeds to be avoided. It does not matter whether Bypass From or Bypass Too is the upper or lower limit, however the Speed Bypass function is disabled if the two parameters are set to the same value.

4-63 Speed Bypass To [Hz]

Range:

Function:

Array [2]

0.0 Hz* [0.0 - 400.0 Hz]

Enter either the upper or lower limit of the speed area to be avoided.
Make sure to enter the **opposite** limit of that in par. 4-61 *Speed Bypass From [Hz]*.

4.6. Parameter Group 5: Digital In/Out

4.6.1. 5-** Digital In/Out


The following describes all digital input command functions and signals.

4.6.2. 5-1* Digital Inputs

Parameters for configuring the functions for the input terminals.

The digital inputs are used for selecting various functions in the frequency converter. All digital inputs can be set to the following:

[0]	No Operation	The frequency converter will not react to signals transmitted to the terminal.
[1]	Reset	Reset the frequency converter after a Trip/Alarm. Not all alarms can be reset.
[2]	Coast Inverse	Coasting stop, inverted input (NC). The frequency converter leaves the motor in free mode.
[3]	Coast and reset inv.	Reset and coasting stop inverted input (NC). The frequency converter resets and leaves the motor in free mode.
[4]	Quick stop inverse	Inverted input (NC). Generates a stop in accordance with the quick-stop ramp time set in par. 3-81. When motor stops, shaft is in free mode.
[5]	DC-brake inv.	Inverted input for DC braking (NC). Stops motor by energizing it with DC current for a certain time period, see par. 2-01. Function is only active when value in par. 2-02 is different from 0.
[6]	Stop inv.	Stop inverted function. Generates stop function when selected terminal goes from logical level "1" to "0". Stop is performed according to selected ramp time.
[8]	Start	Select start for a start/stop command. 1 = Start, 0 = stop.
[9]	Latched start	Motor starts if a pulse is applied for min. 2 ms. Motor stops when Stop inverse is activated.
[10]	Reversing	Change direction of motor shaft rotation. Reversing signal only changes direction of rotation; it does not activate start function. Select <i>Both directions</i> [2] in par. 4.10. 0 = normal, 1 = reversing.
[11]	Start reversing	Use for start/stop and for reversing at the same time. Signals on start [8] are not allowed at the same time. 0 = stop, 1 = start reversing.
[12]	Enable start forward	Use if motor shaft must rotate clockwise at start.
[13]	Enable start reverse	Use if motor shaft must rotate counterclockwise at start.
[14]	Jog	Use for activating jog speed. See par. 3-11.
[16]	Preset ref bit 0	Preset ref bit 0, 1 and 2 enables a choice between one of the eight preset references according to the table below.

[17]	Preset ref bit 1	Same as preset ref bit 0 [16], see par. 3-10.
[18]	Preset ref bit 2	Same as preset ref bit 0 [16].
[19]	Freeze reference	Freeze actual reference. The frozen reference is now the point of enable/condition for Speed up and Speed down to be used. If Speed up/down is used, speed change always follows ramp 2 (par. 3-51 and 3-52) in the range par. 3-02 <i>Minimum Reference</i> - par. 3-03 <i>Maximum Reference</i> .
[20]	Freeze output	Freeze the actual motor frequency (Hz). The frozen motor frequency is now the point of enable/condition for Speed up and Speed down to be used. If Speed up/down is used, the speed change always follows ramp 2 in the range par. 4-12, <i>Motor Speed Low Limit</i> - par. 4-14, <i>Motor Speed High Limit</i> .
		 <p>NB! When freeze output is active, the frequency converter cannot be stopped via a low <i>Start</i>[8] signal. Stop the frequency converter via a terminal programmed for Coasting Inverse [2] or Coast and reset, inverse [3].</p>
[21]	Speed up	Select Speed up and Speed down if digital control of the up/down speed is desired (motor potentiometer). Activate this function by selecting either Freeze reference or Freeze output. When Speed up is activated for less than 400 ms. the resulting reference will be increased by 0.1%. If Speed up is activated for more than 400 ms. the resulting reference will ramp according to ramp 2 in par. 3-51.
[22]	Speed down	Same as Speed up [21].
[23]	Setup select bit 0	Set par. 0-10 <i>Active set-up</i> to Multi set-up. Logic 0 = set-up 1, Logic 1 = Set-up 2.
[26]	Precise stop inverse	Prolong the stop signal to give a precise stop independent of scan time. The function is available for terminal 33 only.
[27]	Start, precise stop	As [26], but including Start.
[28]	Catch up	Select Catch up/Slow down to increase or reduce the resulting reference value by the percentage set in par. 3-12.
[29]	Slow down	Same as Catch up [28]
[32]	Pulse input (only terminal 33)	Select Pulse input when using a pulse sequence as either reference or feedback. Scaling is done in par. group 5-5*.
[34]	Ramp bit 0	Logic 0 = Ramp1, see par. 3-4*. Logic 1 = Ramp2, see par. 3-5*.
[60]	Counter A (up)	Input for counter A.
[61]	Counter A (down)	Input for counter A.
[62]	Reset counter A	Input for reset of counter A.
[63]	Counter B (up)	Input for counter B.
[64]	Counter B (down)	Input for counter B.

[65] Reset counter B Input for reset of counter B.

5-10 Terminal 18 Digital Input

Option:	Function:
[8] * Start	Select function from available digital input range. See par. 5-1* for choices.

5-11 Terminal 19 Digital Input

Option:	Function:
[10] * Reversing	Select function from available digital input range. See par. 5-1* for choices.

5-12 Terminal 27 Digital Input

Option:	Function:
[0] * No Operation	Select function from available digital input range. See par. 5-1* for choices.

5-13 Terminal 29 Digital Input

Option:	Function:
[14] * Jog	Select function from available digital input range. See par. 5-1* for choices.

5-15 Terminal 33 Digital Input

Option:	Function:
[0] * No Operation	Select function from available digital input range. See par. 5-1* for choices.

4.6.3. 5-4* Relays

Parameter group for configuring timing and output functions for relays.

[0]	No Operation	Default for all digital and relay outputs.
[1]	Control Ready	Control board receives supply voltage.
[2]	Drive Ready	Frequency converter is ready for operation and applies supply signal on control board.
[3]	Drive Ready, Remote	Frequency converter is ready for operation in Auto On-mode.
[4]	Enable/No Warning	Frequency converter is ready for operation. No start or stop command is given. No warnings are present.
[5]	Drive Running	Motor is running.
[6]	Running/No Warning	Motor runs, and no warning are present.
[7]	Run in Range/No Warning	Motor runs within programmed current ranges, see parameters 4-50 and 4-51. No warnings are present.

[8]	Run on ref/No Warning	Motor runs at reference speed.
[9]	Alarm	An alarm activates output.
[10]	Alarm on Warning	An alarm or warning activates output.
[12]	Out of Current Range	Motor current is outside range set in parameters 4-50 and 4-51.
[13]	Below Current, low	Motor current is lower than set in par. 4-50.
[14]	Above Current, high	Motor current is higher than set in par. 4-51.
[21]	Thermal Warning	Thermal warning is present when temperature exceeds limit in motor, frequency converter, brake resistor or thermistor.
[22]	Ready, No Thermal Warning	Frequency converter is ready for operation and no over-temperature warning is present.
[23]	Remote Ready, No Thermal Warning	Frequency converter is ready for operation in Auto mode, and no over-temperature warning is present.
[24]	Ready, Voltage OK	Frequency converter is ready for operation and mains voltage is within specified voltage range.
[25]	Reverse	Motor runs/is ready to run clockwise when logic = 0 and counter clockwise when logic = 1. Output changes as soon as reversing signal is applied.
[26]	Bus OK	Active communication (no time-out) via serial communication port.
[28]	Brake, No Warn	Brake is active, and no warnings are present.
[29]	Brake Ready/No Fault	Brake is ready for operation, and no faults are present.
[30]	Brake Fault (IGBT)	Protects frequency converter if fault on brake modules is present. Use relay to cut out main voltage from frequency converter.
[32]	Mech. Brake Control	Enables control of external mechanical brake, see parameter group 2-2*.
[36]	Control Word Bit 11	Bit 11 in control word controls relay.
[51]	Local Ref Active	
[52]	Remote Ref Active	
[53]	No Alarm	
[54]	Start Cmd Active	
[55]	Running Reverse	
[56]	Drive in Hand Mode	
[57]	Drive in Auto Mode	
[60]	Comparator 0	See par. group 13-1*. If comparator 0 is evaluated as TRUE, output goes high. Otherwise, it is low.
[61]	Comparator 1	See par. group 13-1*. If comparator 1 is evaluated as TRUE, output goes high. Otherwise, it is low.
[62]	Comparator 2	See par. group 13-1*. If comparator 2 is evaluated as TRUE, output goes high. Otherwise, it is low.

[63]	Comparator 3	See par. group 13-1*. If comparator 3 is evaluated as TRUE, output goes high. Otherwise, it is low.
[70]	Logic Rule 0	See par. 13-4*. If Logic Rule 1 is evaluated as TRUE, output goes high. Otherwise, it is low.
[71]	Logic Rule 1	See par. 13-4*. If Logic Rule 2 is evaluated as TRUE, output goes high. Otherwise, it is low.
[72]	Logic Rule 2	See par. 13-4*. If Logic Rule 3 is evaluated as TRUE, output goes high. Otherwise, it is low.
[73]	Logic Rule 3	See par. 13-4*. If Logic Rule 3 is evaluated as TRUE, output goes high. Otherwise, it is low.
[81]	SL Digital Output B	See par. 13-52 <i>SL Control Action</i> . When Smart Logic Action <i>Set dig. out. A high</i> [39] is executed, input goes high. When Smart Logic Action <i>Set dig. out. A low</i> [33] is executed, input goes low.

5-40 Function Relay

Option:	Function:
[0]* No Operation	Select function from available relay output range.

4.6.4. 5-5* Pulse Input

Set par. 5-15 to choice [32] pulse input. Now terminal 33 handles a pulse input in the range from Low frequency, par. 5-55, to High frequency, par. 5-56. Scale frequency input via par. 5-57 and par. 5-58.

5-55 Terminal 33 Low Frequency

Range:	Function:
20 Hz* [20 - 4999 Hz]	Enter low frequency corresponding to low motor shaft speed (i.e. low reference value) in par. 5-57.

5-56 Terminal 33 High Frequency

Range:	Function:
5000 Hz* [21 - 5000 Hz]	Enter high frequency corresponding to high motor shaft speed (i.e. high reference value) in par. 5-58.

5-57 Terminal 33 Low Ref./Feedb. Value

Range:	Function:
0.000* [-4999 - 4999]	Set reference/feedback value corresponding to low pulse frequency value set in par. 5-55.

5-58 Terminal 33 High Ref./Feedb. Value

Range:	Function:
50.000* [-4999 - 4999]	Set reference/feedback value corresponding to high pulse frequency value set in par. 5-56.

4.7. Parameter Group 6: Analogue In/Out

4.7.1. 6-** Analog In/Out

Parameter group for configuring analog inputs and outputs.

4.7.2. 6-0* Analog I/O Mode

Parameter group for setting up the analog I/O configuration.

6-00 Live Zero Timeout Time

Range:

10 s [1 - 99 s]

Function:

The Live Zero function is used for monitoring the signal on an analog input. If the signal disappears, a *Live Zero* warning is reported.

Set delay time before *Live Zero Timeout Function* is applied (par. 6-01).
If the signal reappears during the set delay, timer will be reset.
When live zero is detected, the frequency converter freezes output frequency and starts *Live Zero Timeout* timer.

6-01 Live Zero Timeout Function

Option:

[0] * Off

[1] Freeze output

[2] Stop

[3] Jogging

[4] Max Speed

[5] Stop and Trip

Function:

Function is activated if input signal is below 50% of value set in parameters 6-10, 6-12 or 6-22.

Function is disabled.

Output frequency remains at value it had when live zero was detected.

Frequency converter ramps down to 0 Hz. Remove live zero error condition before restarting frequency converter.

Frequency converter ramps to jog speed, see par. 3-41.

Frequency converter ramps to Motor Speed High Limit, see par. 4-14.

Frequency converter ramps down to 0 Hz and then trips. Remove live zero condition and activate reset before restarting the frequency converter.


4.7.3. 6-1* Analog Input 1

Parameters for configuring scaling and limits for analog input 1 (terminal 53).



NB!

Micro switch 4 in position U:
Parameters 6-10 and 6-11 are active.
Micro switch in position I:
Parameters 6-12 and 6-13 are active.



6-10 Terminal 53 Low Voltage

Range: **Function:**
 This scaling value should correspond to minimum reference value set in par. 6-14. See also section *Reference Handling*.

0.07 V* [0.00 - 9.90 V] Enter low voltage value.

6-11 Terminal 53 High Voltage

Range: **Function:**
 This scaling value should correspond to maximum reference value set in par. 6-15.

10.0 V* [0.10 - 10.00 V] Enter high voltage value.

6-12 Terminal 53 Low Current

Range: **Function:**
 This reference signal should correspond to minimum reference value set in par. 3-02.

0.14 mA* [0.00 - 19.90 mA] Enter low current value.

! The value must be set to min. 2 mA in order to activate the Live Zero Timeout function in par. 6-01.

6-13 Terminal 53 High Current

Range: **Function:**
 This reference signal should correspond to the maximum reference value set in par. 6-15.

20.00 mA* [0.10 - 20.00 mA] Enter high current value.

6-14 Terminal 53 Low Ref./Feedb. Value

Range: **Function:**
The scaling value corresponding to the low voltage/low current set in parameters 6-10 and 6-12.

0.000* [-4999 - 4999] Enter analog input scaling value.

6-15 Terminal 53 High Ref./Feedb. Value

Range: **Function:**
The scaling value corresponding to the maximum reference feedback value set in parameters 6-11 and 6-13.

50.00* [-4999 - 4999] Enter analog input scaling value.

6-16 Terminal 53 Filter Time Constant

Range: **Function:**
A first-order digital low pass filter time constant for suppressing electrical noise in terminal 53. A high time constant value improves dampening but also increases time delay through the filter.

0.001 s* [0.001 - 10.00 s] Enter time constant.



NB!

This parameter cannot be adjust while motor is running.

6-19 Terminal 53 Mode

Option: **Function:**
Select the input to be present on terminal 53.



Par. 6-19 MUST be set according to Micro switch 4 setting.

[0] * Voltage Mode

[1] Current Mode

4.7.4. 6-2* Analog Input 2

Parameters for configuring scaling and limits for analog input 2, terminal 60.

6-22 Terminal 60 Low Current

Range: **Function:**
This reference signal should correspond to minimum reference value set in par. 3-02.

0.14 [0.00 - 19.90 mA] Enter low current value.
mA*



The value must be set to min. 2 mA in order to activate the Live Zero Timeout function in par. 6-01.

6-23 Terminal 60 High Current

Range:

Function:

This reference signal should correspond to the high current value set in par. 6-25.

20.00 [0.10 - 20.00 mA]
mA*

Enter high current value.

6-24 Terminal 60 Low Ref./Feedb. Value

Range:

Function:

The scaling value should correspond to the minimum reference feedback value set in par. 3-02.

0.000* [-4999 - 4999]

Enter analog input scaling value.

6-25 Terminal 60 High Ref./Feedb. Value

Range:

Function:

The scaling value should correspond to the maximum reference feedback value set in par. 3-03.

50.00* [-4999 - 4999]

Enter analog input scaling value.

6-26 Terminal 54 Filter Time Constant

Range:

Function:

A first-order digital low pass filter time constant for suppressing electrical noise in terminal 54. A high time constant value improves dampening, but also increases time delay through the filter.



NB!

This parameter cannot be changed while motor runs.

0.001 s* [0.001 - 10.00 s]

Enter time constant.

4.7.5. 6-8* LCP Potmeter

The LCP potmeter can be selected either as Reference Resource or Relative Reference Resource.



NB!

In Hand mode the LCP potmeter functions as local reference.

6-81 LCP Potmeter Low Ref. Value

Range:	Function:
0.000* [-4999 - 4999]	The scaling value corresponding to 0. Enter low reference value. The reference value corresponding to potentiometer turned fully counterclockwise (0 degrees).

6-82 LCP Potmeter High Ref. Value

Range:	Function:
50.00* [-4999 - 4999]	The scaling value corresponding to the maximum reference feedback value set in par. 3-03. Enter high reference value. The reference value corresponding to potentiometer turned fully clockwise (200 degrees).

4.7.6. 6-9* Analog Output

These parameters are for configuring the analog outputs of the frequency converter.

6-90 Terminal 42 Mode

Option:	Function:
[0] * 0 - 20 mA	Range for analog outputs is 0-20 mA
[1] 4-20 mA	Range for analog outputs is 4 - 20 mA
[2] Digital	Functions as slow reacting digital output. Set value to either 0 mA (off) or 20 mA (on), see par. 6-92.

6-91 Terminal 42 Analog Output

Option:	Function:
[0] * No Operation	Select the function for terminal 42 as an analog output.
[10] Output Frequency	
[11] Reference	
[12] Feedback	
[13] Motor Current	
[16] Power	
[17] Speed	


6-92 Terminal 42 Digital Output

Option:	Function:
[80] SL Digital Output A	See par. 5-4*, <i>Relays</i> , for choices and descriptions. See par. 13-52 <i>SL Control Action</i> . When Smart Logic Action <i>Set dig. out. A high</i> [38] is executed, input goes high. When Smart Logic Action <i>Set dig. out. A low</i> [32] is executed, input goes low.

6-93 Terminal 42 Output Min. Scale

Range:
0.00 % [0.00 - 200.0%]

Function:
Scale minimum output of selected analog signal at terminal 42 as percentage of maximum signal value. E.g. if 0 mA (or 0 Hz) is desired at 25% of maximum output value, programme 25%. Scaling values up to 100% can never be higher than corresponding setting in par. 6-52.



6-94 Terminal 42 Output Max. Scale

Range:
100%* [0 - 200%]


Function:
Scale maximum output of selected analog signal at terminal 42. Set value to maximum value of current signal output. Scale output to give a current lower than 20 mA at full scale; or 20 mA at an output below 100% of maximum signal value.

If 20 mA is the desired output current at a value between 0 - 100% of the full-scale output, programme percentage value in the parameter, i.e. 50% = 20 mA. If a current between 4 and 20 mA is desired at maximum output (100%), calculate percentage value as follows:

$$\frac{20 \text{ mA}}{\text{desired maximum current}} \times 100 \%$$

i.e.

$$10 \text{ mA} = \frac{20}{10} \times 100 = 200 \%$$



4.8. Parameter Group 7: Controllers

4.8.1. 7-** Controllers

Parameters group for configuring application controls.

4.8.2. 7-2* Process Ctrl. Feedb

Select feedback sources and handling for Process PI Control.

7-20 Process CL Feedback Resources

Option:	Function:
	Select input to function as feedback signal.

[0] *	No Function
-------	-------------

[1]	Analog Input 53
-----	-----------------

[2]	Analog Input 60
-----	-----------------

[8]	Pulse Input 33
-----	----------------

[11]	Local Bus Ref.
------	----------------

4.8.3. 7-3* Process PI Control

7-30 Process PI Normal/Inverse Control

Option:	Function:
[0] * Normal	Feedback larger than setpoint result in a speed reduction. Feedback less than setpoint result in a speed increase.

[1] Inverse	Feedback larger than setpoint result in a speed increase. Feedback less than setpoint result in a speed reduction.
-------------	---

7-31 Process PI Anti Windup

Option:	Function:
[0] Disable	Regulation of a given error will continue even when the output frequency cannot be increased/decreased.

[1] * Enable	PI-controller ceases from regulating a given error when the output frequency cannot be increased/decreased.
--------------	---

7-32 Process PI Start Speed

Range:	Function:
0.0 Hz* [0.0 - 200.0 Hz]	Until the set motor speed has been reached the frequency converter operates in Open Loop mode.

7-33 Process PI Proportional Gain

Option:	Function:
[0.01] * 0.00 - 10.00	Enter the value for the P proportional gain, i.e. the multiplication factor of the error between the set point and the feedback signal. Note! 0.00 = Off.

7-34 Process PI Integral Time

Range:
9999 s* [0.01 - 999.0 s]

Function:
The integrator provides an increasing gain at a constant error between the set point and the feedback signal. The integral time is the time needed by the integrator to reach the same gain as the proportional gain.

7-38 Process Feed Forward Factor

Range:
0%* [0 - 400%]

Function:
The FF factor sends a part of the reference signal around the PI controller which then only affects part of the control signal. By activating the FF factor less overshoot and high dynamics are gained when changing the setpoint. This parameter is always active when par. 1-00 *Configuration Mode* is set to *Process* [3].

7-39 On Reference Bandwidth

Range:
5% [0 - 200%]

Function:
Enter the value for the On Reference Bandwidth. The PI control error is the difference between setpoint and feedback and when this is less than the value set in this parameter the On Reference is active.

4.9. Parameter Group 8: Communication

4.9.1. 8-** Communication

Parameter group for configuring communication.

4.9.2. 8-0* General Settings

Use this parameter group for configuring the general settings for communication.

8-01 Control Site

Option:	Function:
[0] * Digital and Control Word	Use both digital input and control word as control.
[1] Digital Only	Use digital input as control.
[2] Control Word Only	Use control word only as control.



NB!

The setting in this parameter overrules settings in par. 8-50 to 8-56.

8-02 Control Word Source

Option:	Function:
[0] None	Function is inactive
[1] * FC RS485	Monitoring control word source is done via serial communication port RS485.

8-03 Control Word Timeout Time

Range:	Function:
1.0 s* [0.1 - 6500 s]	Enter time to pass before control word timeout function (par. 8-04) must be carried out.

8-04 Control Word Timeout Function

Option:	Function:
	Select the action to be taken in case of a timeout.
[0] * Off	No function.
[1] Freeze Output	Freeze output until communication resumes.
[2] Stop	Stop with auto restart when communication resumes.
[3] Jogging	Run motor at jog frequency until communication resumes.
[4] Max. Speed	Run motor at max. frequency until communication resumes.
[5] Stop and Trip	Stop motor, then reset frequency converter in order to restart either via LCP or digital input.

[7]	Select Set-up 1	Change to Set-up 1 upon reestablishment of communication following a control word timeout.
[8]	Select Set-up 2	Change to Set-up 2 upon reestablishment of communication following a control word timeout.

8-06 Reset Control Word Timeout

Option:
Function:

Resetting the control word timeout will remove any timeout function.

[0] *	No Function	Control word timeout is not reset.
[1]	Do Reset	Control word timeout is reset, and parameter goes into <i>No Function</i> state.

4.9.3. 8-3* FC Port Settings

Parameters for configuring the FC Port.

4.9.4. 8-30 Protocol

8-30 Protocol

Option:
Function:

Select the protocol to be used. Note that changing protocol will not be effective until after powering off the frequency converter.

[0] *	FC
[2]	Modbus

8-31 Address

Range:
Function:

Select the address for the bus.

1*	[1 - 126]	FC -bus range is 1-126. Modbus range is 1-247.
----	-----------	---

8-32 FC Port Baud Rate

Option:
Function:

Select baud rate for FC Port.


NB!

Changing baud rate will be effective after responding to any ongoing bus-requests.

[0]	2400 Baud
[1]	4800 Baud
[2] *	9600 Baud

8-33 FC Port Parity

Option:

Function:
This parameter only affects Modbus as FC bus always has even parity.

- [0] * No Parity
- [1] Odd parity
- [2] No Parity (2 stopbit)
- [3] No Parity (1 stopbit)

8-35 Minimum Response Delay

Range:
10 ms [1 - 500 ms]

Function:
Specify minimum delay time between receiving a request and transmitting a response.

8-36 Max Response Delay

Range:
5.000 s* [0.010 - 10.00 s]

Function:
Specify maximum permissible delay time between transmitting a request and receiving a response. Exceeding this time delay causes control word timeout.

4.9.5. 8-5* Digital/Bus

Parameters for configuring control word Digital/Bus merging.



NB!

Parameters are only active when par. 8-01, *Control Site*, is set to *Digital and control word* [0].

8-50 Coasting Select

Option:

Function:
Select control of coasting function via digital input and/or bus.

- [0] Digital Input Activation via a digital input.
- [1] Bus Activation via serial communication port.
- [2] LogicAnd Activation via serial communication port and a digital input.
- [3] * LogicOr Activation via serial communication port or a digital input.

8-51 Quick Stop Select

Option:

Function:
Select control of quick stop function via digital input and/or bus.

- [0] Digital Input Activation via a digital input.
- [1] Bus Activation via serial communication port.
- [2] LogicAnd Activation via serial communication port and a digital input.

[3] * LogicOr Activation via serial communication port or a digital input.

8-52 DC Brake Select

Option: **Function:**
Select control of DC brake via digital input and/or bus.

[0] Digital Input Activation via a digital input.

[1] Bus Activation via serial communication port.

[2] LogicAnd Activation via serial communication port and a digital input.

[3] * LogicOr Activation via serial communication port or a digital input.

8-53 Start Select

Option: **Function:**
Select control of start function via digital input and/or bus.

[0] Digital Input Activation via a digital input.

[1] Bus Activation via serial communication port.

[2] LogicAnd Activation via serial communication port and a digital input.

[3] * LogicOr Activation via serial communication port or a digital input.

8-54 Reversing Select

Option: **Function:**
Select control of reversing function via digital input and/or bus.

[0] Digital Input Activation via a digital input.

[1] Bus Activation via serial communication port.

[2] LogicAnd Activation via serial communication port and a digital input.

[3] * LogicOr Activation via serial communication port or a digital input.

8-55 Set-up Select

Option: **Function:**
Select control of set-up selection via digital input and/or bus.

[0] Digital Input Activation via a digital input.

[1] Bus Activation via serial communication port.

[2] LogicAnd Activation via serial communication port and a digital input.

[3] * LogicOr Activation via serial communication port or a digital input.

8-56 Preset Reference Select

Option: **Function:**
Select control of Preset Reference selection via digital input and/or bus.

[0] Digital Input Activation via a digital input.

[1]	Bus	Activation via serial communication port.
[2]	LogicAnd	Activation via serial communication port and a digital input.
[3] *	LogicOr	Activation via serial communication port or a digital input.

4.9.6. 8-9* Bus Feedback

Parameter for configuring bus feedback.

8-94 Bus Feedback 1

Range:

0* [0x8000 - 0x7FFF]

Function:

Bus feedback is delivered via FC or Modbus by writing the feedback value into this parameter.

4.10. Parameter Group 13: Smart Logic

4.10.1. 13-** Programming Features


Smart Logic Control (SLC) is a sequence of user defined actions (par. 13-52 [X]) executed by the SLC when the associated user defined event (par. 13-51 [X]) is set to *True*.

Events and actions are linked in pairs, meaning that when an event is true, the linked action is carried out. After this the next event is evaluated and its belonging action carried out and so on. Only one event is evaluated at the time.

If an event is evaluated as *False*, the SLC takes no action during the scan interval and no other events are evaluated.

It is possible to programme from 1 to 6 events and actions. When the last event/action has been executed, the sequence starts again from event/action [0].

The drawing shows an example with three events/actions:



Starting and stopping the SLC:

Start the SLC by selecting *On* [1] in par. 13-00. The SLC starts evaluating Event 0, and if this is evaluated as TRUE, the SLC continues its cycle.

The SLC stops when the *Stop Event*, par. 13-02, is TRUE. The SLC can also be stopped by selecting *Off* [0] in par. 13-00.

To reset all SLC parameters select *Reset SLC* [1] in par. 13-03 and start programming from scratch.

4.10.2. 13-0* SLC Settings

Use SLC settings to activate, deactivate and reset the Smart Logic Control.

13-00 SL Controller Mode

Option:	Function:
[0] * Off	Function is disabled.
[1] On	SLC is active.

13-01 Start Event

Option:	Function:
	Select input to activate Smart Logic Control.
[0] False	Enters <i>False</i> in logic rule.
[1] True	Enters <i>True</i> in logic rule.
[2] Running	See par. 5-4* [5] for description.
[3] InRange	See par. 5-4* [7] for description.
[4] OnReference	See par. 5-4* [8] for description.
[7] Out of Current Range	See par. 5-4* [12] for description.
[8] BelowILow	See par. 5-4* [13] for description.
[9] AboveIHigh	See par. 5-4* [14] for description.
[16] ThermalWarning	See par. 5-4* [21] for description.
[17] MainsOutOfRange	Mains voltage is outside the specified voltage range.
[18] Reversing	See par. 5-4* [25] for description.
[19] Warning	A warning is active.
[20] Alarm_Trip	A trip alarm is active.
[21] Alarm_TripLock	A trip lock alarm is active.
[22] Comparator 0	Use result of comparator 0 in logic rule.
[23] Comparator 1	Use result of comparator 1 in logic rule.
[24] Comparator 2	Use result of comparator 2 in logic rule.
[25] Comparator 3	Use result of comparator 3 in logic rule.
[26] LogicRule 0	Use result of logic rule 0 in logic rule.
[27] LogicRule 1	Use result of logic rule 1 in logic rule.
[28] LogicRule 2	Use result of logic rule 2 in logic rule.
[29] LogicRule 3	Use result of logic rule 3 in logic rule.
[33] DigitalInput_18	Use value of DI 18 in logic rule.
[34] DigitalInput_19	Use value of DI 19 in logic rule.
[35] DigitalInput_27	Use value of DI 27 in logic rule.
[36] DigitalInput_29	Use value of DI 29 in logic rule.
[39] * StartCommand	This event is <i>True</i> , if frequency converter is started by any means (digital input or other).

[40]	DriveStopped	This event is <i>True</i> , if frequency converter is stopped or coasted by any means (digital input or other).
------	--------------	---

13-02 Stop Event

Option:
Function:

Select input to activate Smart Logic Control.

[0]	False	Enters <i>False</i> in logic rule.
[1]	True	Enters <i>True</i> in logic rule.
[2]	Running	See par. 5-4* [5] for description.
[3]	InRange	See par. 5-4* [7] for description.
[4]	OnReference	See par. 5-4* [8] for description.
[7]	Out of Current Range	See par. 5-4* [12] for description.
[8]	BelowILow	See par. 5-4* [13] for description.
[9]	AboveIHigh	See par. 5-4* [14] for description.
[16]	ThermalWarning	See par. 5-4* [21] for description.
[17]	MainsOutOfRange	Mains voltage is outside the specified voltage range.
[18]	Reversing	See par. 5-4* [25] for description.
[19]	Warning	A warning is active.
[20]	Alarm_Trip	A trip alarm is active.
[21]	Alarm_TripLock	A trip lock alarm is active.
[22]	Comparator 0	Use result of comparator 0 in logic rule.
[23]	Comparator 1	Use result of comparator 1 in logic rule.
[24]	Comparator 2	Use result of comparator 2 in logic rule.
[25]	Comparator 3	Use result of comparator 3 in logic rule.
[26]	LogicRule 0	Use result of logic rule 0 in logic rule.
[27]	LogicRule 1	Use result of logic rule 1 in logic rule.
[28]	LogicRule 2	Use result of logic rule 2 in logic rule.
[29]	LogicRule 3	Use result of logic rule 3 in logic rule.
[30]	SL Timeout0	Use result of timer 0 in logic rule.
[31]	SL Timeout1	Use result of timer 1 in logic rule.
[32]	SL Timeout2	Use result of timer 2 in logic rule.
[33]	DigitalInput_18	Use value of DI 18 in logic rule.
[34]	DigitalInput_19	Use value of DI 19 in logic rule.
[35]	DigitalInput_27	Use value of DI 27 in logic rule.
[36]	DigitalInput_29	Use value of DI 29 in logic rule.

[39]	StartCommand	This event is <i>True</i> , if frequency converter is started by any means (digital input or other).
[40] *	DriveStopped	This event is <i>True</i> , if frequency converter is stopped or coasted by any means (digital input or other).

13-03 Reset SLC

Option:

[0] * Do Not Reset

Function:

Retains all settings programmed in parameter group 13.

[1] Reset SLC

Reset all group 13 parameters to default settings.

4

4.10.3. 13-1* Comparators

Comparators are used for comparing continuous variables (i.e. output frequency, output current, analog input etc.) to fixed preset values. In addition, there are digital values that will be compared to fixed time values. See explanation in par. 13-10. Comparators are evaluated once in each scan interval. Use the result (TRUE or FALSE) directly. All parameters in this parameter group are array parameters with index 0 to 5. Select index 0 to programme Comparator 0, select index 1 to programme Comparator 1, and so on.

13-10 Comparator Operand

Array [4]

		Select variable to be monitored by comparator.
[0] *	Disabled	Comparator is disabled.
[1]	Reference	Resulting remote reference (not local) as a percentage.
[2]	Feedback	Feedback in either [RPM] or [Hz].
[3]	MotorSpeed	Motor speed in Hz.
[4]	MotorCurrent	Motor current in [A].
[6]	MotorPower	Motor power in either [kW] or [Hz].
[7]	MotorVoltage	Motor voltage in [V].
[8]	DCLinkVoltage	DC-link voltage in [V].
[9]	MotorThermal	Expressed as a percentage.
[10]	DriveThermal	Expressed as a percentage.
[11]	HeatSink Temperature	Expressed as a percentage.
[12]	AnalogInput53	Expressed as a percentage.
[13]	AnalogInput60	Expressed as a percentage.
[18]	PulseInput33	Expressed as a percentage.
[20]	AlarmNumber	Shows number of the alarm.
[30]	CounterA	Number of counts.
[31]	CounterB	Number of counts.

13-11 Comparator Operator

Array [4]

Select operator to be used in comparison.

[0]	Less Than <	Result of evaluation is <i>True</i> if variable selected in par. 13-10 is smaller than fixed value in par. 13-12. Result is <i>False</i> if variable selected in par. 13-10 is greater than fixed value in par. 13-12.
[1] *	Approximately equals ≈	Result of evaluation is <i>True</i> if variable selected in par. 13-10 is approximately equal to fixed value in par. 13-12.
[2]	Greater Than >	Inverse logic of option [0].

13-12 Comparator Value

Array [4]

0.0* [-9999 - 9999] Enter "trigger level" for variable monitored by this comparator.

4.10.4. 13-2* Timers

Use the timer results to define an event (par. 13-51) or as boolean input in a logic rule (par. 13-40, 13-42 or 13-44).

When timer value has elapsed timer changes state from *False* to *True*.

13-20 SL Controller Timer

Array [3]

0.0 s* [0.0 - 3600 s] Enter value to define duration of the *False* output from programmed timer. A timer is only *False* if it is started by an action and until the given timer value has elapsed.

4.10.5. 13-4* Logic Rules

Combine up to three boolean inputs (TRUE / FALSE inputs) from timers, comparators, digital inputs, status bits and events using the logical operators AND, OR, and NOT. Select boolean inputs for the calculation in par. 13-40, 13-42, and 13-44. Define the operators used to logically combine the selected inputs in par. 13-41 and 13-43.

Priority of calculation

The results of par. 13-40, 13-41, and 13-42 are calculated first. The outcome (TRUE / FALSE) of this calculation is combined with the settings of par. 13-43 and 13-44, yielding the final result (TRUE / FALSE) of the logic rule.

13-40 Logic Rule Boolean 1

Array [4]

Select first boolean input for selected logic rule.

[0] *	False	Enters <i>False</i> in logic rule.
[1]	True	Enters <i>True</i> in logic rule.
[2]	Running	See par. 5-4* [5] for description.
[3]	InRange	See par. 5-4* [7] for description.

[4]	OnReference	See par. 5-4* [8] for description.
[7]		See par. 5-4* [12] for description.
[8]	BelowILow	See par. 5-4* [13] for description.
[9]	AboveIHigh	See par. 5-4* [14] for description.
[16]	ThermalWarning	See par. 5-4* [21] for description.
[17]	MainsOutOfRange	Mains voltage is outside the specified voltage range.
[18]	Reversing	See par. 5-4* [25] for description.
[19]	Warning	A warning is active.
[20]	Alarm_Trip	A trip alarm is active.
[21]	Alarm_TripLock	A trip lock alarm is active.
[22]	Comparator 0	Use result of comparator 0 in logic rule.
[23]	Comparator 1	Use result of comparator 1 in logic rule.
[24]	Comparator 2	Use result of comparator 2 in logic rule.
[25]	Comparator 3	Use result of comparator 3 in logic rule.
[26]	LogicRule 0	Use result of logic rule 0 in logic rule.
[27]	LogicRule 1	Use result of logic rule 1 in logic rule.
[28]	LogicRule 2	Use result of logic rule 2 in logic rule.
[29]	LogicRule 3	Use result of logic rule 3 in logic rule.
[30]	SL Timeout0	Use result of timer 0 in logic rule.
[31]	SL Timeout1	Use result of timer 1 in logic rule.
[32]	SL Timeout2	Use result of timer 2 in logic rule.
[33]	DigitalInput_18	Use value of DI 18 in logic rule.
[34]	DigitalInput_19	Use value of DI 19 in logic rule.
[35]	DigitalInput_27	Use value of DI 27 in logic rule.
[36]	DigitalInput_29	Use value of DI 29 in logic rule.
[39]	StartCommand	This event is <i>True</i> , if frequency converter is started by any means (digital input or other).
[40]	DriveStopped	This event is <i>True</i> , if frequency converter is stopped or coasted by any means (digital input or other).

13-41 Logic Rule Operator 1

Array [4]

		Select first logical operator to use on boolean inputs from par. 13-40 and 13-42.
[0] *	Disabled	Ignores parameters 13-42, 13-43 and 13-44.
[1]	And	Evaluates expression [13-40] AND [13-42].
[2]	Or	Evaluates expression [13-40] OR [13-42].

[3]	And not	Evaluates expression [13-40] AND NOT [13-42].
[4]	Or not	Evaluates expression [13-40] OR NOT [13-42].
[5]	Not and	Evaluates expression NOT [13-40] and [13-42].
[6]	Not or	Evaluates expression NOT [13-40] OR [13-42].
[7]	Not and not	Evaluates expression NOT [13-40] AND [13-40].
[8]	Not or not	Evaluates expression NOT [13-40] OR NOT [13-42].

13-42 Logic Rule Boolean 2

Array [4]

Select second boolean input for selected logic rule.
See par. 13-40 for choices and descriptions.

13-43 Logic Rule Operator 2

Array [4]

Select second logical operator to use on boolean inputs calculated in par. 13-40, 13-41, and 13-42 and the boolean input from par. 13-42.

[0] *	Disabled	Ignores parameter 13-44.
[1]	And	Evaluates expression [13-40/13-42] AND [13-44].
[2]	Or	Evaluates expression [13-40/13-42] OR [13-44].
[3]	And not	Evaluates expression [13-40/13-42] AND NOT [13-44].
[4]	Or not	Evaluates expression [13-40/13-42] OR NOT [13-44].
[5]	Not and	Evaluates expression NOT [13-40/13-42] and [13-44].
[6]	Not or	Evaluates expression NOT [13-40/13-42] OR [13-44].
[7]	Not and not	Evaluates expression NOT [13-40/13-42] AND [13-44].
[8]	Not or not	Evaluates expression NOT [13-40/13-42] OR NOT [13-44].

13-44 Logic Rule Boolean 3

Array [4]

Select third boolean input for selected logic rule.
See par. 13-40 for choices and descriptions.

4.10.6. 13-5* States

Parameters for programming the Smart Logic Controller.

13-51 SL Controller Event

Array [20]

Select boolean input to define Smart Logic Controller Event.
See par. 13-40 for choices and descriptions.

13-52 SL Controller Action

Array [20]

		Select action corresponding to SLC event. Actions are executed when corresponding event (par. 13-51) is evaluated as <i>True</i> .
[0] *	Disabled	Function is disabled.
[1]	No Action	No action is taken.
[2]	Select Set-up1	Changes active set-up to Set-up 1.
[3]	Select Set-up2	Changes active set-up to Set-up 2.
[10]	SelectPresetRef0	Selects preset reference 0
[11]	SelectPresetRef1	Selects preset reference 1
[12]	SelectPresetRef2	Selects preset reference 2
[13]	SelectPresetRef3	Selects preset reference 3
[14]	SelectPresetRef4	Selects preset reference 4
[15]	SelectPresetRef5	Selects preset reference 5
[16]	SelectPresetRef6	Selects preset reference 6
[17]	SelectPresetRef7	Selects preset reference 7
[18]	SelectRamp1	Selects ramp 1
[19]	SelectRamp2	Selects ramp 2
[22]	Run	Issues start command to frequency converter.
[23]	RunReverse	Issues start reverse command to frequency converter.
[24]	Stop	Issues stop command to frequency converter.
[25]	Qstop	Issues quick stop command to frequency converter.
[26]	DCstop	Issues DC stop command to frequency converter.
[27]	Coast	Frequency converter coasts immediately. All stop commands including coast command stop the SLC.
[28]	Freeze Output	Freezes output frequency.
[29]	StartTimer0	Starts timer 0.
[30]	StartTimer1	Starts timer 1
[31]	StartTimer2	Starts timer 2
[32]	SetDO42Low	Digital output 42 is low.
[33]	SetRelayLow	Relay is low.
[38]	SetDO42High	Digital output 42 is high.
[39]	SetRelayHigh	Relay is high.
[60]	ResetCounterA	Resets counter A to 0.
[61]	ResetCounterB	Resets counter B to 0.

4.11. Parameter Group 14: Special Functions

4.11.1. 14-** Special Functions

Parameter group for configuring special frequency converter functions.

4.11.2. Inverter Switching, 14-0*

Parameters for configuring the inverter switching.

14-01 Switching Frequency

Option: **Function:**
Select the switching frequency in order to minimize e.g. acoustic noise and power loss or maximizing efficiency.

[0] 2 KHz

[1] * 4 KHz

[2] 8 KHz

[3] 12 KHz

[4] 16 KHz

14-03 Overmodulation

Option: **Function:**
This feature allows more accurate speed control near and over nominal speed (50/60 Hz). Another advantage with overmodulation is the ability of staying at a constant speed even though mains is dropping.

[0] Off Disables the overmodulation function to avoid torque ripple on the motor shaft.

[1] * On Connects the overmodulation function to obtain an output voltage up to 15% greater than mains voltage.

4.11.3. 14-1* Mains Monitoring

This parameter group supplies functions for handling imbalance on mains.

14-12 Functions at Mains Imbalance

Option: **Function:**
Operation under severe mains imbalance conditions reduces drive lift time.
Select function to take place when severe mains imbalance is detected.

[0] * Trip Frequency converter trips.

[1] Warning Frequency converter issues a warning.

[2] Disabled No action taken.

4.11.4. Trip Reset, 14-2*

Parameters for configuring auto reset handling, special trip handling and control card self test or initialisation.

14-20 Reset Mode

Option:
Function:

Select reset function after tripping. Once reset, frequency converter can be restarted.

[0] *	Manual Reset	Perform reset via [reset]-button or digital inputs.
[1]	AutoReset 1	Performs one automatic reset after tripping.
[2]	AutoReset 2	Performs two automatic resets after tripping.
[3]	AutoReset 3	Performs three automatic resets after tripping.
[4]	AutoReset 4	Performs four automatic resets after tripping.
[5]	AutoReset 5	Performs five automatic resets after tripping.
[6]	AutoReset 6	Performs six automatic resets after tripping.
[7]	AutoReset 7	Performs seven automatic resets after tripping.
[8]	AutoReset 8	Performs eight automatic resets after tripping.
[9]	AutoReset 9	Performs nine automatic resets after tripping.
[10]	AutoReset 10	Performs ten automatic resets after tripping.
[11]	AutoReset 15	Performs fifteen automatic resets after tripping.
[12]	AutoReset 20	Performs twenty automatic resets after tripping.
[13]	Infinite auto reset	Performs an infinite number of automatic resets after tripping.



Motor may start without warning.

14-21 Automatic Restart Time

Range:

10 s* [0 - 600 s]

Function:

Enter time interval from trip to start of automatic reset function. This parameter is active when par. 14-20, *Reset Mode*, is set to *Automatic Reset* [0] - [13].

14-22 Operation Mode

Option:	Function:
	Use this parameter for specifying normal operation or to initialize all parameters, except par. 15-03, 15-04 and 15-05.
[0] * Normal Operation	Frequency converter runs normal operation.
[2] Initialization	Resets all parameters to default settings, except for 15-03, 15-04 and 15-05. Frequency converter resets during next power-up.
	Par. 14-22 also reverts to default setting <i>Normal Operation</i> [0].

4.11.5. 14-4* Energy Optimizing

These parameters are for adjusting the energy optimization level in both Variable Torque (VT) and Automatic Energy Optimization (AEO) modes.

14-41 AEO Minimum Magnetization

Range:	Function:
66%* [40 - 75%]	Enter the minimum allowable magnetization for AEO. Selecting a low value reduces energy loss in the motor, but may also reduce resistance to sudden load changes.

4.12. Parameter Group 15: Drive Information

4.12.1. 15-** Drive Information

Parameter group containing information on operating data, hardware configuration, software version, etc.

4.12.2. 15-0* Operating Data

Parameter group containing operating data e.g. Operating Hours, kWh counters, Power Ups, etc.

4.12.3. 15-00 Operating Time

15-00 Operating Time

Range:	Function:
0 days* [0 - 65535 days]	View running hours of frequency converter. The value is saved at power off and cannot be reset.

15-01 Running Hours

Range:	Function:
0* [0 - 2147483647]	View running hours of motor. The value is saved at power off and can be reset in par. 15-07, <i>Reset Running Hours Counter</i> .

15-02 kWh Counter

Range:	Function:
0 [0 - 65535]	View power consumption in kWh as a mean value over one hour. Reset counter in par. 15-06, <i>Reset kWh Counter</i> .

15-03 Power Ups

Range:	Function:
0 [0 - 2147483647]	View number of times frequency converter has been powered up. Counter cannot be reset.

15-04 Over Temps

Range:	Function:
0 [0 - 65535]	View number of times frequency converter has tripped due to over temperature. Counter cannot be reset.

15-05 Over Volts

Range:	Function:
0* [0 - 65535]	View number of times frequency converter has tripped due to over voltage.

Counter cannot be reset.

15-06 Reset kWh Counter

Option: **Function:**
This parameter cannot be selected via serial port RS 485.

[0] *	Do Not Reset	Counter is not reset.
[1]	Reset Counter	Counter is reset.

15-07 Reset Running Hours Counter

Option: **Function:**
This parameter cannot be selected via serial port RS 485.

[0] *	Do Not Reset	Counter is not reset.
[1]	Reset Counter	Counter is reset.

4.12.4. 15-3* Fault Log

This parameter group contains a fault log showing reasons for the ten latest trips.

15-30 Fault Log: Error Code

Range: **Function:**
0 [0 - 255] View error code and look it up in VLT Micro Design Guide.

4.12.5. Drive Identification, 15-4*

Parameters containing read only information about the hardware and software configuration of the frequency converter.

15-40 FC Type

Option: **Function:**
View FC type.

15-41 Power Section

Option: **Function:**
View power section of frequency converter.

15-42 Voltage

Option: **Function:**
View voltage of frequency converter.

15-43 Software Version

Option: **Function:**
View software version of frequency converter.

15-46 Frequency Converter Ordering No**Option:****Function:**

View ordering number for re-ordering frequency converter in its original configuration.

15-48 LCP ID No**Option:****Function:**

View LCP ID number.

15-51 Frequency Converter Serial Number**Option:****Function:**

View frequency converter serial number.

4.13. Parameter Group 16: Data Readouts

4.13.1. 16-** Data Readouts

Parameter group for data read-outs, e.g. actual references, voltages, control, alarm, warning and status words.

4.13.2. 16-0* General Status

Parameters for reading the general status, e.g. the calculated reference, the active control word, status.

16-00 Control Word

Range:	Function:
0* [0 - 65535]	View latest valid control word sent to frequency converter via serial communication port.

16-01 Reference [Unit]

Range:	Function:
0.000* [-4999.000 4999.000]	- View total remote reference. Total reference is sum of pulse, analog, preset, LCP potmeter, local bus and freeze reference.

16-02 Reference %

Range:	Function:
0.00* [-200.0 - 200.0%]	View total remote reference in percent. Total reference is sum of pulse, analog, preset, LCP potmeter, local bus and freeze reference.

16-03 Status Word

Range:	Function:
0* [0 - 65535]	View status word sent to frequency converter via serial communication port.

16-05 Main Actual Value %

Range:	Function:
0.00* [-100.00 - 100.00%]	View two-byte word sent with status word to bus Master reporting main actual value.

4.13.3. 16-1* Motor Status

Parameters for reading the motor status values.

16-10 Power [kW]

Range:	Function:
0 kW* [0 - 99 kW]	View output power in kW.

16-11 Power [hp]

Range:
0 hp [0 - 99 hp]

Function:
View output power in hp.

16-12 Motor Voltage

Range:
0.0* [0.0 - 999.9 V]

Function:
View motor phase voltage.

16-13 Frequency

Range:
0.0 Hz* [0.0 - 400.0 Hz]

Function:
View output frequency in Hz.

16-14 Motor Current

Range:
0.00 A* [0.00 - 1856.00 A]

Function:
View motor phase current.

16-15 Frequency [%]

Range:
0.00* [-100.00 - 100.00%]

Function:
View a two-byte word reporting actual motor frequency as a percentage of par. X-XX

16-18 Motor Thermal

Range:
0%* [0 - 100%]

Function:
View calculated thermal motor load as percentage of estimated thermal motor load.

4.13.4. 16-3* Drive Status

Parameters for reporting the status of the frequency converter.

16-30 DC Link Voltage

Range:
0 V* [0 - 10000 V]

Function:
View DC-link voltage.

16-34 Heat Sink Temp.

Range:
0* [0 - 255]

Function:
View heat sink temperature of frequency converter.

16-35 Inverter Thermal

Range:
0%* [0 - 100%]

Function:
View calculated thermal load on frequency converter in relation to estimated thermal load on frequency converter.

16-36 Inv. Nom. Current

Range:	Function:
0.00 A* [0.01 - 10000.00 A]	View continuous nominal inverter current.

16-37 Inv. Max. Current

Range:	Function:
0.00 A* [0.1 - 10000.00 A]	View intermittent maximum inverter current (150%).

16-38 SL Controller State

Range:	Function:
0* [0 - 255]	View number of active SLC state.

4.13.5. 16-5* Ref. & Feedb.

Parameters for reporting the reference and feedback input.

16-50 External Reference

Range:	Function:
0.0%* [-200.0 - 200.0%]	View sum of all external references in percent.

16-51 Pulse Reference

Range:	Function:
0.0 %* [-200.0 - 200.0%]	View actual pulse input converted to a reference in percent.

16-52 Feedback

Range:	Function:
0.000* [-4999.000 4999.000]	- View analog or pulse feedback in Hz.

4.13.6. 16-6* Inputs and Outputs

Parameters for reporting the digital and analog IO ports.

16-60 Digital Input 18, 19, 27, 33

Range:	Function:
0* [0 - 1111]	View signal states from active digital inputs.

16-61 Digital Input 29

Range:	Function:
0* [0 - 1]	View signal state on digital input 29.

16-62 Analog Input 53 (volt)

Range:	Function:
0.00* [0.00 - 10.00 V]	View input voltage on analog input terminal.

16-63 Analog Input 53 (current)

Range:	Function:
0.00* [0.00 - 20.00 mA]	View input current on analog input terminal.

16-64 Analog Input 60

Range:	Function:
0.00* [0.00 - 20.00 mA]	View actual value at input 60 either as reference or protection value.

16-65 Analog Output 42 [mA]

Range:	Function:
0.00 [0.00 - 20.00 mA] mA*	View output current on analog output 42.

16-68 Pulse Input

Range:	Function:
20 Hz* [20 - 5000 Hz]	View input frequency on pulse input terminal.

16-71 Relay Output [bin]

Range:	Function:
0* [0 - 1]	View relay setting.

16-72 Counter A

Range:	Function:
0* [-2147483648 2147483647]	- View present value of Counter A.

16-73 Counter B

Range:	Function:
0* [-2147483648 2147483647]	- View present value of Counter B.

4.13.7. 16-8* FC Port

Parameter for viewing references from FC Port.

16-86 FC Port REF 1

Range:	Function:
0* [0x8000 - 0x7FFF]	View currently received reference from FC Port.

4.13.8. 16-9* Diagnosis Read-Out

Parameters displaying alarm, warning and extended status words.

16-90 Alarm Word

Range:	Function:
0* [0 - 0x7FFFFFFFUL]	Via alarm word sent via serial communication port in hex code.

16-92 Warning Word

Range:	Function:
0* [0 - 0x7FFFFFFFUL]	View warning word sent via serial communication port in hex code.

16-94 Ext. Status Word

Range:	Function:
0* [0 - 0xFFFFFFFFFUL]	View extended warning word sent via serial communication port in hex code.

5. Parameter Lists

Parameter Overview	Parameter Overview	Parameter Overview	Parameter Overview
0-** Operation/Display	1-0* General Settings	1-00 Configuration Mode	1-61 High Speed Load Compensation
0-0* Basic Settings	1-00 Speed open loop	*[0] Speed open loop	0 - 199 % * 100 %
0-03 Regional Settings	*[3] Process	1-01 Motor Control Principle	1-62 Brake Resistor (ohm)
*[0] International	[1] US	[0] U/f	5 - 5000 * 5
0-04 Oper. State at Power-up (Hand)	*[1] VVC+	1-03 Torque Characteristics	2-16 AC Brake, Max current
*[1] Resume	*[0] Constant torque	*[2] Automatic Energy Optim.	0 - 150 % * 100 %
[2] Forced stop, ref = 0	0-10 Active Set-up	1-05 Local Mode Configuration	2-17 Over-voltage Control
0-1* Set-up Handling	*[1] Setup 1	*[0] Speed Open Loop	*[0] Disabled
*[2] Setup 2	[9] Multi Setup	*[2] As config in param. 1-00	[1] Enabled (not at stop)
0-11 Edit Set-up	*[1] Setup 1	1-2* Motor Data	[2] Enabled
[2] Setup 2	[9] Active Setup	1-20 Motor Power [kW] [HP]	2-2 Mechanical Brake
[9] Not Linked	*[20] Linked	0.09 kW / 0.12 HP ... 11 kW / 15 HP	2-20 Release Brake Current
0-12 Link Setups	0-4* LCP Keypad	1-22 Motor Voltage	0.00 - 100.0 A * 0.00 A
[0] Disabled	[0] Hand on] Key on LCP	50 - 999 V * 230 - 400 V	2-22 Activate Brake Speed [Hz]
*[1] Enabled	*[1] Enabled	20 - 400 Hz * 50 Hz	0.0 - 400.0 Hz * 0.0 Hz
0-41 [Off / Reset] Key on LCP	0-40 [Hand on] Key on LCP	1-24 Motor Current	3-0* Reference / Ramps
[0] Disable All	*[1] Enabled	0.01 - 26.00 A * Motortype dep.	3-00 Reference Range
*[1] Enable All	0-42 [Auto on] Key on LCP	1-25 Motor Nominal Speed	*[0] Min - Max
[2] Enable Reset Only	[0] Disabled	100 - 9999 rpm * Motortype dep.	3-02 Minimum Reference
0-42 [Auto on] Key on LCP	*[1] Enabled	1-29 Automatic Motor Tuning (AMT)	-4999 - 4999 * 0.000
[0] Disabled	[0] Disable All	*[0] Off	3-03 Maximum Reference
*[1] Enabled	*[1] Enable All	[2] Enable AMT	-4999 - 4999 * 50.00
0-5* Copy/Save	0-42 [Auto on] Key on LCP	1-3* Adv. Motor Data	3-1* References
*[0] No copy	[0] Disabled	[0hm] * Dep. on motor data	3-10 Preset Reference
[1] All to LCP	*[1] Enabled	1-33 Stator Leakage Reactance (X1)	-100.0 - 100.0 % * 0.00 %
[2] All from LCP	0-50 LCP Copy	[0hm] * Dep. on motor data	3-11 Jog Speed [Hz]
[3] Size indep. from LCP	*[0] No copy	1-35 Main Reactance (Xh)	0.0 - 400.0 Hz * 5.0 Hz
0-51 Set-up Copy	[1] Copy from setup 1	[0hm] * Dep. on motor data	3-12 Catch up/slow Down Value
[0] No copy	[2] Copy from setup 2	1-5 Load Indep. Setting	0.00 - 100.0 % * 0.00 %
[1] All to LCP	[9] Copy from Factory setup	1-50 Motor Magnetisation at 0 Speed	3-14 Preset Relative Reference
[2] All from LCP	0-60 (Main) Menu Password	0 - 300 % * 100 %	-100.0 - 100.0 % * 0.00 %
[3] Size indep. from LCP	0 - 999 * 0	1-52 Min Speed Norm. Magnet. [Hz]	3-15 Reference Resource 1
0-51 Set-up Copy	1-** Load/Motor	0.0 - 10.0 Hz * 0.0 Hz	[0] No function
*[0] No copy		1-55 U/f Characteristic - U	*[1] Analog Input 53
[1] Copy from setup 1		0 - 999.9 V	[2] Analog input 60
[2] Copy from setup 2		1-56 U/f Characteristic - F	[8] Pulse input 33
[9] Copy from Factory setup		0 - 400 Hz	[11] Local bus ref
0-6* Password		1-60 Low Speed Load Compensation	[21] Lcp Potentiometer
0 - 999 * 0		0 - 199 % * 100 %	3-16 Reference Resource 2
1-** Load/Motor			[0] No function
			*[1] Analog Input 53
			[2] Analog input 60
			[8] Pulse input 33
			[11] Local bus ref
			[21] Lcp Potentiometer
			3-16 Reference Resource 2
			[0] No function
			[1] Analog Input 53
			*[2] Analog input 60
			[8] Pulse input 33
			[11] Local bus ref
			[21] Lcp Potentiometer

<p>3-17 Reference Resource 3 [0] No function [1] Analog input 53 [2] Analog input 60 [8] Pulse input 33 *[11] Local bus ref [21] Lcp Potentiometer</p> <p>3-18 Relative Scaling Ref. Resource *[0] No function [1] Analog Input 53 [2] Analog input 60 [8] Pulse input 33 [11] Local bus ref [21] Lcp Potentiometer</p> <p>3-4* Ramp 1 *[0] Linear [2] Sine2 ramp</p> <p>3-41 Ramp 1 Ramp up Time 0.05 - 3600 s * 3.00 s</p> <p>3-42 Ramp 1 Ramp Down Time 0.05 - 3600 s * 3.00 s</p> <p>3-5* Ramp 2</p> <p>3-50 Ramp 2 Type *[0] Linear [2] Sine2 ramp</p> <p>3-51 Ramp 2 Ramp up Time 0.05 - 3600 s * 3.00 s</p> <p>3-52 Ramp 2 Ramp down Time 0.05 - 3600 s * 3.00 s</p> <p>3-8* Other Ramps</p> <p>3-80 Jog Ramp Time 0.05 - 3600 s * 3.00 s</p> <p>3-81 Quick Stop Ramp Time 0.05 - 3600 s * 3.00 s</p> <p>4* * Limits / Warnings</p> <p>4-1* Motor Limits [0] Clockwise [1] CounterClockwise *[2] Both</p> <p>4-12 Motor Speed Low Limit [Hz] 0.0 - 400.0 Hz * 0.0 Hz</p> <p>4-14 Motor Speed High Limit [Hz] 0.1 - 400.0 Hz * 65.0 Hz</p> <p>4-16 Torque Limit Motor Mode 0 - 400 % * 150 %</p>	<p>4-17 Torque Limit Generator Mode 0 - 400 % * 100 %</p> <p>4-5* Adj. Warnings</p> <p>4-50 Warning Current Low 0.00 - 26.00 A * 0.00 A</p> <p>4-51 Warning Current High 0.00 - 26.00 A * 26.00 A</p> <p>4-58 Missing Motor Phase Function *[0] Off *[1] On 4-6* Speed Bypass</p> <p>4-61 Bypass Speed From [Hz] 0.0 - 400.0 Hz * 0.0 Hz</p> <p>4-63 Bypass Speed To [Hz] 0.0 - 400.0 Hz * 0.0 Hz</p> <p>5-1* Digital Inputs</p> <p>5-10 Terminal 18 Digital Input [0] No function [1] Reset [2] Coast inverse [3] Coast and reset inv. [4] Quick stop inverse [5] DC-brake inv. [6] Stop inv *[8] Start [9] Latched start [10] Reversing [11] Start reversing [12] Enable start forward [13] Enable start reverse [14] Jog [16-18] Preset ref bit 0-2 [19] Freeze reference [20] Freeze output [21] Speed up [22] Speed down [23] Setup select bit 0 [28] Catch up [29] Slow down [34] Ramp bit 0 [60] Counter A (up) [61] Counter A (down) [62] Reset counter A [63] Counter B (up) [64] Counter B (down) [65] ResetCounter B</p>	<p>5-11 Terminal 19 Digital Input See par. 5-10. * [10] Reversing</p> <p>5-12 Terminal 27 Digital Input See par. 5-10. * [1] Reset</p> <p>5-13 Terminal 29 Digital Input See par. 5-10. * [14] Jog</p> <p>5-15 Terminal 33 Digital Input See par. 5-10. * [16] Preset ref bit 0 [26] Precise Stop Inverse [27] Start, Precise Stop [32] Pulse Input</p> <p>5-4* Relays</p> <p>5-40 Function Relay *[0] No operation [1] Control ready [2] Drive ready [3] Drive ready, Remote [4] Enable / No warning [5] Drive running [6] Running / No warning [7] Run in range / No warning [8] Run on ref / No warning [9] Alarm [10] Alarm or warning [12] Out of current range [13] Below current, low [14] Above current, high [21] Thermal warning [22] Ready, No thermal warning [23] Remote ready, No thermal warning [24] Ready, Voltage ok [25] Reverse [26] Bus ok [28] Brake, NoWarn [29] Brake ready/NoFault [30] BrakeFault (IGBT) [32] Mech.brake control [36] Control word bit 11 [51] Local ref. active [52] Remote ref. active [53] No alarm [54] Start cmd active [55] Running reverse [56] Drive in hand mode [57] Drive in auto mode [60-63] Comparator 0-3</p>	<p>[70-73] Logic rule 0-3 [81] SL digital output B</p> <p>5-5* Pulse Input 5-55 Terminal 33 Low Frequency 2.0 - 4999 Hz * 20 Hz</p> <p>5-56 Terminal 33 High Frequency 2.1 - 5000 Hz * 5000 Hz</p> <p>5-57 Term. 33 Low Ref./Feedb. Value -4999 - 4999 * 0.000</p> <p>5-58 Term. 33 High Ref./Feedb. Value -4999 - 4999 * 50.000</p> <p>6-* Analog In/Out</p> <p>6-0* Analog I/O Mode</p> <p>6-00 Live Zero Timeout Time 1 - 99 s * 10 s</p> <p>6-01 Live Zero TimeoutFunction *[0] Off [1] Freeze output [2] Stop [3] Jogging [4] Max speed [5] Stop and trip</p> <p>6-1* Analog Input 1</p> <p>6-10 Terminal 53 Low Voltage 0.00 - 9.99 V * 0.07 V</p> <p>6-11 Terminal 53 High Voltage 0.01 - 10.00 V * 10.00 V</p> <p>6-12 Terminal 53 Low Current 0.00 - 19.99 mA * 0.14 mA</p> <p>6-13 Terminal 53 High Current 0.01 - 20.00 mA * 20.00 mA</p> <p>6-14 Term. 53 Low Ref./Feedb. Value -4999 - 4999 * 0.000</p> <p>6-15 Term. 53 High Ref./Feedb. Value -4999 - 4999 * 50.000</p> <p>6-16 Terminal 53 Filter Time Constant 0.01 - 10.00 s * 0.01 s</p> <p>6-19 Terminal 53 mode *[0] Voltage mode [1] Current mode</p> <p>6-2* Analog Input 2</p> <p>6-22 Terminal 60 Low Current 0.00 - 19.99 mA * 0.14 mA</p> <p>6-23 Terminal 60 High Current 0.01 - 20.00 mA * 20.00 mA</p>
---	--	--	---

6-24 Term. 60 Low Ref./Feedb. Value -4999 - 4999 * 0.000	7-31 Process PI Anti Windup [0] Disable *[1] Enable	8-33 FC Port Parity *[0] Even Parity, 1 Stop Bit [1] Odd Parity, 1 Stop Bit	[8] BelowLow
6-25 Term. 60 High Ref./Feedb. Value -4999 - 4999 * 50.00	7-32 Process PI Start Speed 0.0 - 200.0 Hz * 0.0 Hz	[2] No Parity, 1 Stop Bit [3] No Parity, 2 Stop Bits	[9] AboveHigh
6-26 Terminal 60 Filter Time Constant 0.01 - 10.00 s * 0.01 s	7-33 Process PI Proportional Gain 0.00 - 10.00 * 0.01	8-35 Minimum Response Delay 0.001-0.5 * 0.010 s	[16] ThermalWarning
6-8* LCP potmeter -4999 - 4999 * 0.000	7-34 Process PI Integral Time 0.10 - 9999 s * 9999 s	8-36 Max Response Delay 0.100 - 10.00 s * 5.000 s	[17] MainOutOfRange
6-81 LCP potm. Low Reference -4999 - 4999 * 50.00	7-38 Process PI Feed Forward Factor 0 - 400 % * 0 %	8-5* Digital/Bus [0] DigitalInput [1] Bus	[18] Reversing
6-82 LCP potm. High Reference -4999 - 4999 * 50.00	7-39 On Reference Bandwidth 0 - 200 % * 5 %	[2] LogicAnd *[3] LogicOr	[19] Warning
6-9* Analog Output xx 6-90 Terminal 42 Mode *[0] 0-20 mA [1] 4-20 mA	8-** Comm. and Options 8-0* General Settings 8-01 Control Site *[0] Digital and ControlWord [1] Digital only [2] ControlWord only	8-50 Coasting Select [0] DigitalInput [1] Bus [2] LogicAnd *[3] LogicOr	[20] Alarm_Trip
6-91 Terminal 42 Analog Output *[0] No operation [10] Output Frequency [11] Reference [12] Feedback [13] Motor Current [16] Power [20] BusControl See par. 5-40 *[0] No Operation [80] SL Digital Output A	8-02 Control Word Source *[0] None *[1] FC RS485	8-51 Quick Stop Select See par. 8-50 * [3] LogicOr	[21] Alarm_TripLock
6-93 Terminal 42 Output Min Scale 0.00 - 200.0 % * 0.00 %	8-03 Control Word Timeout Time 0.1 - 6500 s * 1.0 s	8-52 DC Brake Select See par. 8-50 * [3] LogicOr	[22-25] Comparator 0-3
6-94 Terminal 42 Output Max Scale 0.00 - 200.0 % * 100.0 %	8-04 Control Word Timeout Function *[0] Off [1] Freeze Output [2] Stop [3] Jogging [4] Max. Speed [5] Stop and trip	8-53 Start Select See par. 8-50 * [3] LogicOr	[26-29] LogicRule0-3
7-** Controllers 7-2* Process Ctrl. Feedb 7-20 Process CL Feedback 1 Resource *[0] NoFunction [1] Analog Input 53 [2] Analog input 60 [8] PulseInput33 [11] LocalBusRef	8-06 Reset Control Word Timeout *[0] No Function [1] Do reset	8-54 Reversing Select See par. 8-50 * [3] LogicOr	[30] CounterA
7-3* Process PI Ctrl. 7-30 Process PI Normal/ Inverse Ctrl *[0] Normal [1] Inverse	8-30 Protocol *[0] FC [2] Modbus	8-55 Set-up Select See par. 8-50 * [3] LogicOr	[31] CounterB
	8-31 Address 1 - 247 * 1	8-56 Preset Reference Select See par. 8-50 * [3] LogicOr	[0] Less Than
	8-32 FC Port Baud Rate [0] 2400 Baud [1] 4800 Baud *[2] 9600 Baud	8-9* Bus Jog / Feedback 8-94 Bus feedback 1 0x8000 - 0x7FFF * 0	
		13-00 SL Controller Mode *[0] Off [1] On	
		13-01 Start Event [0] False [1] True	
		13-0* SLC Settings 13-00 SL Controller Mode *[0] Off [1] On	
		13-01 Start Event [0] False [1] True	
		13-02 Stop Event See par. 13-01 * [40] DriveStopped	
		13-03 Reset SLC *[0] Do not reset [1] Reset SLC	
		13-1* Comparators 13-10 Comparator Operand *[0] Disabled [1] Reference [2] Feedback [3] MotorSpeed [4] MotorCurrent [6] MotorPower [7] MotorVoltage [8] DCLinkVoltage [12] AnalogInput53 [13] AnalogInput60 [18] PulseInput33 [20] AlarmNumber [30] CounterA [31] CounterB	

[1] Approximately equals	[31] StartTimer2	15-04 Over Temps	16-3 Drive Status
[2] Greater Than	[32] Set Digital Output A Low	15-05 Over Volts	16-30 DC Link Voltage
13-12 Comparator Value	[33] Set Digital Output B Low	15-06 Reset kWh Counter	16-36 Inv. Nom. Current
-9999 - 9999 * 0.0	[38] Set Digital Output A High	*[0] Do not reset	16-37 Inv. Max. Current
13-2* Timers	[39] Set Digital Output B High	[1] Reset counter	16-38 SL Controller State
13-20 SL Controller Timer	[60] ResetCounterA	15-07 Reset Running Hours Counter	16-5* Ref. / Feedb.
0.0 - 3600 s * 0.0 s	[61] ResetCounterB	*[0] Do not reset	16-50 External Reference
13-4* Logic Rules	14** Special Functions	[1] Reset counter	16-51 Pulse Reference
13-40 Logic Rule Boolean 1	14-0* Inverter Switching	15-3* Fault Log	16-52 Feedback [Unit]
See par. 13-01 * [0] False	14-01 Switching Frequency	15-30 Fault Log: Error Code	16-5* Inputs / Outputs
[30] - [32] SL Time-out 0-2	[0] 2 kHz	15-4* Drive Identification	16-60 Digital Input 18,19,27,33
13-41 Logic Rule Operator 1	*[1] 4 kHz	15-40 FC Type	0 - 1111
*[0] Disabled	[2] 8 kHz	15-41 Power Section	16-61 Digital Input 29
[1] And	[4] 16 kHz	15-42 Voltage	0 - 1
[2] Or	14-03 Overmodulation	15-43 Software Version	16-62 Analog Input 53 (volt)
[3] And not	[0] Off	15-46 Frequency Converter Order. No	16-63 Analog Input 53 (current)
[4] Or not	*[1] On	15-48 LCP Id No	16-64 Analog Input 60
[5] Not and	14-1* Mains monitoring	15-51 Frequency Converter Serial No	16-65 Analog Output 42 [mA]
[6] Not or	14-12 Function at mains imbalance	16-** Data Readouts	16-68 Pulse Input [Hz]
[7] Not and not	*[0] Trip	16-0* General Status	16-71 Relay Output [bin]
[8] Not or not	[1] Warning	16-00 Control Word	16-72 Counter A
13-42 Logic Rule Boolean 2	[2] Disabled	16-01 Reference [Unit]	16-73 Counter B
See par. 13-40	14-2* Trip Reset	-4999 - 4999	16-8* Fieldbus / FC Port
13-43 Logic Rule Operator 2	14-20 Reset Mode	16-02 Reference %	16-86 FC Port REF 1
See par. 13-41 * [0] Disabled	*[0] Manual reset	-200.0 - 200.0 %	0x8000 - 0x7FFF
13-44 Logic Rule Boolean 3	[1-9] AutoReset 1-9	16-03 Status Word	16-9* Diagnosis Readouts
See par. 13-40	[10] AutoReset 10	0 - 0XFFFF	16-90 Alarm Word
13-5* States	[11] AutoReset 15	16-05 Main Actual Value [%]	0 - 0XFFFFFFF
13-51 SL Controller Event	[12] AutoReset 20	16-1* Motor Status	16-92 Warning Word
See par. 13-40	[13] Infinite auto reset	16-10 Power [kW]	0 - 0XFFFFFFF
13-52 SL Controller Action	14-21 Automatic Restart Time	16-11 Power [hp]	16-94 Ext. Status Word
*[0] Disabled	0 - 600 s * 10 s	16-12 Motor Voltage [V]	0 - 0XFFFFFFF
[1] NoAction	14-22 Operation Mode	16-13 Frequency [Hz]	0 - 0XFFFFFFF
[2] SelectSetup1	*[0] Normal Operation	16-14 Motor Current [A]	0 - 0XFFFFFFF
[3] SelectSetup2	[2] Initialisation	16-15 Frequency [%]	0 - 0XFFFFFFF
[10-17] SelectPresetRef0-7	14-26 Action At Inverter Fault	16-18 Motor Thermal [%]	
[18] SelectRamp1	*[0] Trip		
[19] SelectRamp2	[1] Warning		
[22] Run	14-4* Energy Optimising		
[23] RunReverse	14-41 AEO Minimum Magnetisation		
[24] Stop	40 - 75 % * 66 %		
[25] Qstop	15-** Drive Information		
[26] DCstop	15-0* Operating Data		
[27] Coast	15-00 Operating Days		
[28] FreezeOutput	15-01 Running Hours		
[29] StartTimer0	15-02 kWh Counter		
[30] StartTimer1	15-03 Power Ups		

6. Troubleshooting

No.	Description	Warning	Alarm	Trip Lock	Cause of Problem
2	Live zero error	X	X		Signal on terminal 53 or 60 is less than 50% of value set in par. 6-10, 6-12 and 6-22.
4	Mains phase loss ¹⁾	X	X	X	Missing phase on supply side, or too high voltage imbalance. Check supply voltage.
7	DC over voltage ¹⁾	X	X		Intermediate circuit voltage exceeds limit.
8	DC under voltage ¹⁾	X	X		Intermediate circuit voltage drops below "voltage warning low" limit.
9	Inverter overloaded	X	X		More than 100% load for too long.
10	Motor ETR over temperature	X	X		Motor is too hot due to more than 100% load for too long.
11	Motor thermistor over temperature	X	X		Thermistor or thermistor connection is disconnected.
12	Torque limit	X	X		Torque exceeds value set in either par. 4-16 or 4-17.
13	Over Current	X	X	X	Inverter peak current limit is exceeded.
14	Earth fault		X	X	Discharge from output phases to ground.
16	Short Circuit		X	X	Short-circuit in motor or on motor terminals.
17	Control word timeout	X	X		No communication to frequency converter.
25	Brake resistor short-circuited		X	X	Brake resistor is short-circuited, thus brake function is disconnected.
27	Brake chopper short-circuited		X	X	Brake transistor is short-circuited, thus brake function is disconnected.
28	Brake check		X		Brake resistor is not connected/working
29	Power board over temp	X	X	X	Heat-sink cut-out temperature has been reached.
30	Motor phase U missing		X	X	Motor phase U is missing. Check the phase.
31	Motor phase V missing		X	X	Motor phase V is missing. Check the phase.
32	Motor phase W missing		X	X	Motor phase W is missing. Check the phase.
38	Internal fault		X	X	Contact local Danfoss supplier.
47	Control Voltage Fault	X	X	X	24 V DC may be overloaded.
51	AMT check U_{nom} and I_{nom}		X		Wrong setting for motor voltage, motor current and motor voltage.
52	AMT low I_{nom}		X		Motor current is too low. Check settings.
59	Current limit		X		VLT overload.
63	Mechanical Brake Low		X	X	Actual motor current has not exceeded "release brake" current within "start delay" time window.
80	Drive Initialised to Default Value		X		All parameter settings are initialized to default settings.

¹⁾ These faults may be caused by mains distortions. Installing Danfoss Line Filter may rectify this problem.

Table 6.1: Code list

Index

1

16-1* Motor Status	71
--------------------------	----

A

Abbreviations And Standards	8
-----------------------------------	---

D

Display	9
Disposal Instruction	4
Drive Identification, 15-4*	69

E

Earth Leakage Current	3
Electronic Waste	4

G

General Warning	8
-----------------------	---

I

Indicator Lights	11
Inverter Switching, 14-0*	65
It Mains	4

L

Lcp	9, 10
Leakage Current	4

M

Main Menu	10
Motor Direction	10

N

Navigation Keys	11
Not Changeable During Operation	15

O

Operation Keys	11
----------------------	----

P

Parameter Number	10
------------------------	----

Q

Quick Menu	10
------------------	----

R

Rated Magnetizing Current	21
Residual Current Device	4

S

Set-up Number	9
Set-up Software	9
Special Functions	65
Status Menu	10

T

Trip Reset, 14-2*	66
Type Code String	7

U

Unit	10
------	----

V

Value	10
-------	----